

Part No	Part Names	Models		Brand
0-28650835-0	BOLT; RET TO C	TFR-03	KBZ	Isuzu
0-28651040-0	BOLT; EXH PIPE	TFR-05	UBS	Isuzu
0-91111508-0	NUT, ADJ.SCREW T	TFR-07	TL75HP	Isuzu
0-91180210-0	NUT; GEN	TFR-03	D-MAX	Isuzu
1-09104027-1	BOLT; FRAM	TFR-05	D-MAX	Isuzu
1-09625320-0	SEAL; OIL, CRANK (100-135-10)	FXM/NK		Isuzu
1-11261240-0	LINER; CYL (GRD 1-AX)	6BB/6BD1		Isuzu
1-11261242-0	LINER; CYL (GRD 2-AX)	6BB/6BD1	JCM	Isuzu
1-11261243-0	LINER; CYL (GRD 2-CX)	6BB/6BD1	JCM	Isuzu
1-12235027-1	BOLT; CONN ROD	FTM/Z		Isuzu
1-12561072-0	SPRING; VALVE, OUTER	FXZ23T		Isuzu
1-12561073-0	SPRING; VALVE, INNER	FXZ23T		Isuzu
1-12561089-0	SPRING; VLV, OU/I	FSR/MT	FSR	Isuzu
1-12562057-0	SPRING; VLV, IN/INL	FSR/MT1		Isuzu
1-13770085-0	THERMOSTAT	FXZ 95		Isuzu
1-21437324-A	HOSE	FVM/Z		Isuzu
1-31240735-2	DISC; CLUTCH	FXZ23T		Isuzu
1-41552017-0	WASHER; THRUST	FVM-11		Isuzu
1-47500251-0	CLUTCH; MASTER CYLINDER	FTR33	FV33 195HP	Isuzu
1-51630180-A	U ABSORB ASM; S	FV12 32	6BG1	Isuzu
1-74417062-0	REGULATOR	FV/FX	FVM 175HP	Isuzu
1-74417063-0	REGULATOR	FV/FX	FVM 175HP	Isuzu
3-44050012-0	WEATHER STRIP DOOR	QFR 89	QFR 89	Isuzu
5-09470002-0	CROMMET SCR	TFR-03	KBZ	Isuzu
5-09583118-0	SPRING; RETURN	KS8NK		Isuzu
5-11721016-0	GUIDE VALVE INL	TFRNK06	KBZ 85HP	Isuzu
5-12565004-0	COOLAR; SPLIT	FRR-11		Isuzu
5-33263001-0	INSERT, SYN.TOP-	NKTFR-05	TL 75HP	Isuzu
5-33264010-0	SPRING, INSERT, C	KB/PF	KBD 69HP	Isuzu
5-86701753-0	BUMPER; RR (SET)PRIMER	TFR-07	D-MAX 07	Isuzu
5-86701902-0	BUMPER; RR	TFR-05	D-MAX 05	Isuzu
5-86760049-0	BONNET GUARD	TFR-08	D-MAX 07 08	Isuzu
5-86760050-0	GRILLE RAD.COLOR KEY	TFR-08	D-MAX 07	Isuzu
5-86760050-1	GRILLE RAD.COLOR KEY	TFR-07	D-MAX 07	Isuzu
5-86760051-1	CHROME GRILLE BUMPER UNDER	TFR-08	D-MAX 08	Isuzu
5-86760156-0	GRILLE "SPEED"	TFR-08	D-MAX 08	Isuzu
5-86760205-1	FRAME FOG LAMP CHROME	TFR-09	D-MAX 09	Isuzu
5-86760322-0	FR BUMPER ACCESS	TFR-10	D-MAX 10	Isuzu
5-87830813-A	CLUTCH RUBBER LOWER	TFR 98		Isuzu
5-87831204-0	REPAIR KIT; CLU	NPNQ 06		Isuzu
5-87831659-0	REPAIR KIT; CLU,	TFR 97	TFR 2.5T	Isuzu
5-87832026-0	CUP SET; RR WHEEL CYL	TFR-03	D-MAX 03	Isuzu
5-87832026-A	REP KIT BRAKE		D-MAX 03	Isuzu
5-87832048-0	M/T MUA 5 SPEED	TFR-03	D-MAX	Isuzu
5-87832049-0	M/T MSG 5 SPEED	TFR-03	D-MAX	Isuzu
5-87832068-0	CUP SET; RR WHEEL	TFR-07		Isuzu
5-87832068-A	REP KIT BRAKE		D-MAX 07	Isuzu
5-87832090-0	SHOE KIT; BRK, RR.4X4	TFS-03	D-MAX 4X4	Isuzu

Part No	Part Names	Models		Brand
5-87870028-0	LINING KIT; RR B	NPR59	NPR 120HP	Isuzu
5-88711180-1	CATALOGUE		D-MAX 09	Isuzu
8-15326386-0	SENSOR; WATER	TFR-03	D-MAX	Isuzu
8-93290859-1	PANEL ROOF	TFR-CAB4	D-MAX CAB4	Isuzu
8-93291049-2	PANEL; CENTER INN LH	TFR-CAB4	D-MAX CAB4	Isuzu
8-93291050-3	PANEL; CENTER INN RH	TFR-CAB4	D-MAX CAB4	Isuzu
8-93291097-6	PANEL; RR DOOR OUT LH	TFR-CAB4	TFR CAB4	Isuzu
8-93291098-6	PANEL; RR DOOR OUT RH	TFR-CAB4	TFR CAB4	Isuzu
8-93295306-0	LOCK; DR RR, LH WO/HAN	TFR-CAB4		Isuzu
8-93295307-0	LOCK; DR RR RH WO/HAN	TFR-CAB4	D-MAX CAB4	Isuzu
8-93295497-4	PANEL SIDE OUTER	TFR-CAB4	D-MAX CAB 4	Isuzu
8-93295498-4	PANEL; SIDE OUTER RH	TFR-CAB4	D-MAX CAB4	Isuzu
8-93297269-2	LID; ASM; FUEL FILLER	TFR-CAB4	TFR CAB-4	Isuzu
8-93297655-1	PANEL RR SIDE LH	TF-CAB4	D-MAX	Isuzu
8-93297656-2	PANEL; RR SIDE RH	TFR-CAB4	D-MAX CAB4	Isuzu
8-93333501-5	REINFORCEMENT; CTR LH	TFR-CAB4		Isuzu
8-94113323-2	BUSH	NKR501		Isuzu
8-94117866-0	FAN; COOLING (7L)	UBS		Isuzu
8-94145839-1	GASKET CYL HD	NPR 88		Isuzu
8-94152344-0	ARM; ROCKER	TFR 97		Isuzu
8-94152344-A	ARM; ROCKER			Isuzu
8-94152558-0	SPRING, INSERT 1	TFR	TFR 87HP	Isuzu
8-94152558-1	SPRING, INSERT 1	TFR	TFR 87HP	Isuzu
8-94156589-0	OIL SEAL	TFR 97	TFR 97	Isuzu
8-94156589-A	OIL SEAL		TFR 97	Isuzu
8-94157885-A	CAB MTG; RUBBER FRT	CAMEO	CAMEO	Isuzu
8-94161988-2	BEARING	TFR		Isuzu
8-94161994-0	BEARING	TFR-03		Isuzu
8-94215211-0	CLIP, ANCHOR, COV	TFR-03	KBZ 85HP	Isuzu
8-94218027-0	CLIP; RADIATOR G	KBZ/FTR3		Isuzu
8-94227041-0	BRG; HUB OUTER FRT	TFS/UBS	TFS	Isuzu
8-94227041-A	ARM; ROCKER	TFS/UBS	TFS 90HP	Isuzu
8-94239423-0	WASHER VALVE EXH	TFR-07	D-MAX 05	Isuzu
8-94240372-0	BELT; COOLING FAN	NKR 55	NKR 55	Isuzu
8-94242683-0	BEARING; HUB IN	TF/WFR	TFR 87HP	Isuzu
8-94242683-A	BEARING; HUB IN	TF/WFR	TFR 87HP	Isuzu
8-94242913-0	BEARING; HUB OU	TF/WFR	TFR 87HP	Isuzu
8-94242913-A	BEARING; HUB OU M12610/M12649	TF/WFR	TFR 87HP	Isuzu
8-94244409-0	CLUTCH ASM, COOL	TFR	KBZ 85HP	Isuzu
8-94244409-A	CLUTCH ASM; COOL	TFR	KBZ 85HP	Isuzu
8-94258597-A	HOSE; WATER TOP	NPR	NKR100HP	Isuzu
8-94258819-0	BRG; HUB, INNER	TFS/UBS	TFS	Isuzu
8-94258819-A	BEARING; HUB INN F.	TFS/UBS	TFS	Isuzu
8-94271020-5	REGULATOR.RH	QFR 91	QFR 91	Isuzu
8-94284381-A	SEAL ASM:WAIST	QFR 89	QFR 98	Isuzu
8-94284382-A	WAIST SEAL; INNER.LH	QFR 89	QFR 89	Isuzu
8-94311258-0	FAN; COOLING (8L)	UBS	UBS	Isuzu
8-94316996-0	ARM'SHIFT; DO TO TOP	NPR/NQR		Isuzu

Part No	Part Names	Models		Brand
8-94317627-0	COVER; DUST, FRT	TFR	TFR	Isuzu
8-94324073-0	LENS; S/LMP RR R	TFR		Isuzu
8-94326441-0	SEAL, OIL, FRT.CV (27-43-9)	NK,KB,TF		Isuzu
8-94334906-0	ELEMENT; AIR FIL 12	TFR	TFR 87HP	Isuzu
8-94336315-2	SEAL; OIL, OUTER	NKR-06		Isuzu
8-94336317-2	SEAL; OIL HUB (49-100-8)	NP/NQ-06	KS21 100HP	Isuzu
8-94340695-A	BRG.KIT C/SH	TFR	KBZDI 87HP	Isuzu
8-94358581-0	BUFFER; DOOR	FRR-11	TROOPER	Isuzu
8-94358581-A	BUFFER; ENG.HOOD FRT		D-MAX	Isuzu
8-94367286-0	H/B CBL; INTERM A/T	TFR	TFR 87HP	Isuzu
8-94367287-A	H/B CABLE; INTER	TFS	TFS 8 7HP	Isuzu
8-94372193-1	BRG.KIT; CONN	TFR	KBZDI 87HP	Isuzu
8-94381233-0	SEAL; OIL CRANK,	UBS		Isuzu
8-94382246-0	HOSE WATER PIPE+4JA1	TFR 97		Isuzu
8-94385029-2	SEAT; SPRING	NPNQFTR		Isuzu
8-94385664-0	SEAL; OIL LIP, A/T	TFS-05	D-MAX 05 4X4	Isuzu
8-94394127-0	SEAT; VLV INSERT	NKNPNQFT		Isuzu
8-94396609-2	SEAL; VLV GUIDE	NPNQFTFV		Isuzu
8-94399526-1	SEAT; SPRING	NPNQ 06	FTR32 195HP	Isuzu
8-94408139-B	CAP; RADIATOR	TFR	KBZDI 87HP	Isuzu
8-94429847-0	BEARING; HUB	UBS	UBS	Isuzu
8-94433672-A	BUSH; STRUT BAR	TFR 97	TFR 87HP	Isuzu
8-94435308-1	PIN; CROSS.DIFF PINION	TFR 97	TFR 97	Isuzu
8-94438305-1	TAPPET	NKUBSTF		Isuzu
8-94442162-1	HOSE	TFR	TFR 87HP	Isuzu
8-94446355-1	SCREW; TAIL GATE LOCK	TFR-03		Isuzu
8-94450917-0	GASKET; PLUG, OIL FIL	TFR 01	D-MAX	Isuzu
8-94455461-A	CABLE; ENGING	TFR 94	TFR 87HP	Isuzu
8-94459459-A	BUSH; STABILIZER	TFR 96		Isuzu
8-94460517-0	SWITCH; VACUUM,	TFR 2000	TFR 87HP	Isuzu
8-94462559-0	GASKET; HEAD CO	NPR		Isuzu
8-94469524-1	GEAR; COUNTER 16/20 31/37/17	TFR 91		Isuzu
8-94472118-0	COLLAR; DISTANC	TFR/UBS		Isuzu
8-94473304-2	GEAR	TFR-03		Isuzu
8-94473720-0	D/MIRROR ASM LH	TF/QFR91	TFR 87HP	Isuzu
8-94475205-1	HOSE W/OIL	TFR	TFR 87HP	Isuzu
8-94478865-0	FAN GUIDE	TFR	TFR 87HP	Isuzu
8-94482366-C	LAMP ASM; RR COMB (RH)	TFR 95	TFR 90HP	Isuzu
8-97014258-1	ARM; ROCKER	NPR(4HF)	NPR 120HP	Isuzu
8-97014258-2	ARM; ROCKER	NP/NQ-06	NPR 120HP	Isuzu
8-97023373-0	SEAL; OIL C/S FRT.	UBS	UBS	Isuzu
8-97023559-0	SPRING; VALVE	NPR 06		Isuzu
8-97031820-0	SWITCH; PARKING BRAKE	TFR 97	TFR 97	Isuzu
8-97032847-1	CYLINDER; SLAVE	NPR(4HF)		Isuzu
8-97039189-3	RUBBER; ENG FOOT, FRT	UBS	UBS	Isuzu
8-97043528-0	SCREW; HOLE COVER, TA	TFR-11	TFR 97	Isuzu
8-97046705-3	SEAL; OIL, RR CO	TFR05C19		Isuzu
8-97086076-1	RUBB CUSHION EN	UBS	UBS	Isuzu

Part No	Part Names	Models		Brand
8-97087619-2	RUBBER; SEAL OIL	NPR		Isuzu
8-97087622-2	RUBBER; SEAL OIL	NPR		Isuzu
8-97087625-2	RUBBER; SEAL OIL	NPR		Isuzu
8-97087628-2	RUBBER; SEAL OIL	NPR		Isuzu
8-97090584-A	HOSE; WATER (LOW)	NPR 95	NPR 120HP	Isuzu
8-97105690-2	GASKET; HD	NP/NQ-06		Isuzu
8-97110314-0	AIR ADM; FRT BUB	TFR 97		Isuzu
8-97116796-0	COVER; FRT, TRANS CASE	TFR 97		Isuzu
8-97120138-0	BUSHING; RUBBER, S/ABS	TFS-03	TFR	Isuzu
8-97120307-0	SEAL VALVE INLE (KBZ/NKR		Isuzu
8-97123342-0	GASKET	TFR-03		Isuzu
8-97123692-0	SEAL; DUST, DRIVE SHF	TFS-03	D-MAX 03 4X4	Isuzu
8-97124740-0	HOSE; WATER RAD; OUT	NKR 97		Isuzu
8-97130560-0	BELT; SERPENTINE DRIV	UBS 99	UBS 99	Isuzu
8-97130567-1	SLEEVE; RUBBER, HOSE	UBS	UBS	Isuzu
8-97130757-1	BLADE; COOLING FAN	UBS 99	UBS 99	Isuzu
8-97134857-1	GEAR; CLUTCH	UBS	UBS	Isuzu
8-97136256-1	PULLEY; TENSION	UBS 99		Isuzu
8-97146877-0	PULLEY; IDLE TIMING	UBS 99		Isuzu
8-97148270-1	CARTRIDGE; OIL FILTER (8-97136647-0)	FRR-11		Isuzu
8-97162962-1	BOOSTER ASM; CLUTCH	NPR 06		Isuzu
8-97165879-2	REGULATOR; DOOR	TFR 97		Isuzu
8-97173035-1	RELAY; PTO CONT	FRR-11	NPR	Isuzu
8-97176230-0	SWITCH; OIL PRESSURE	FRR-11	NQR 06	Isuzu
8-97176686-0	LINER; CYL	NKR501	NKR 88HP	Isuzu
8-97176688-0	LINER; CYL	NKR501	NKR 88HP	Isuzu
8-97179967-0	BULB; COMB.LAMP12V21W	TFR-03	D-MAX	Isuzu
8-97184735-0	REPAIR KIT; OIL PUMP	TFR 98	TFR 98	Isuzu
8-97188174-1	SHAFT; AXLE, FRT INN	TFS-03		Isuzu
8-97193713-0	SENSOR; ACCEL	TFR-05	D-MAX 05	Isuzu
8-97209197-0	BEARING; CLUCTH	TFR-03		Isuzu
8-97214813-0	BOLT; LWR LINK TO FRT	TFR-03	D-MAX 4X2	Isuzu
8-97214815-1	BAR; STAB.FT.SUSP.	TFR-03	D-MAX	Isuzu
8-97214995-1	PUMP ASM; OIL P/S	TFR-03		Isuzu
8-97215052-0	RUBBER; BUMPER STRUT	TFR-03		Isuzu
8-97215330-0	HANDLE; SPARE TIRE	TFR-03	D-MAX	Isuzu
8-97215332-0	HANDLE; SPARE TIRE	TFR-03	D-MAX	Isuzu
8-97215333-1	HANGER; SPARE T	UCR/S 05	UCR/S	Isuzu
8-97216792-0	SEAL; OIL RR HUB OUT	TFR-03		Isuzu
8-97216797-0	BEARING; RR, AXLE 4X2-4X4	TFR-03	D-MAX	Isuzu
8-97216797-2	BEARING; RR, AXLE 4X2-4X4	TFR-03	D-MAX	Isuzu
8-97217788-1	JACK ASM; (4X4)	TFS-03	D-MAX 4X4	Isuzu
8-97217789-1	JACK ASM; (4X2) 8-98154177-0	TFR-03		Isuzu
8-97219456-0	MATAL; SET C/S	NKNPNQ50		Isuzu
8-97220043-0	BUSHING; UPR LINK 4X2	TFR-03	D-MAX	Isuzu
8-97234350-0	TANK ASM; OIL.P/S	TFR-03	D-MAX	Isuzu
8-97234752-6	FENDER; FRT.RH. (4X2)	TFR-03	D-MAX	Isuzu
8-97234753-6	FENDER; FRT.LH. (4X2)	TFR-03	D-MAX	Isuzu

Part No	Part Names	Models		Brand
8-97234754-6	FENDER; FRT.RH	TFS-03	D-MAX 4X4	Isuzu
8-97234755-6	FENDER; FRT.LH	TFS-03	D-MAX	Isuzu
8-97234863-1	PANEL; WHL.HOUSE IN.R	TFR-03	D-MAX S/C	Isuzu
8-97234864-1	PANEL; WHL.HOUSE IN.L	TFR-03	D-MAX S/C	Isuzu
8-97234874-1	PANEL; SIDE GATE RH	TFR-03	D-MAX 4X4	Isuzu
8-97234875-1	PANEL; WHL HOUSE, IN.L	TFR-03	D-MAX4X4	Isuzu
8-97234909-1	COVER; RR GATE	TFR-03		Isuzu
8-97234932-2	SEDIMENTOR; FUEL 4JH1	TFR-03	TFR 3.0	Isuzu
8-97234964-4	PANEL; WHEEL HOUSE RH	TFR-03	D-MAX	Isuzu
8-97234978-1	REINFORCEMENT; BODY R	TFR-03		Isuzu
8-97234979-1	REINFORCEMENT; BODY L	TFR-03	D-MAX	Isuzu
8-97235045-1	REINFORCEMENT; ROCKER	TFR-03	D-MAX SP/CAB	Isuzu
8-97235054-1	REINFORCEMENT; ROCK L	TFR-03	D-MAX SP/CAB	Isuzu
8-97235057-2	REINFORCEMENT COWL R	TFR-03	D-MAX 03	Isuzu
8-97235058-2	REINFORCEMENT COM1.	TFR-03	D-MAX	Isuzu
8-97235070-4	PANEL; F.PILLAR IN RH	TFR-03	D-MAX	Isuzu
8-97235072-4	PANEL; F.PILLAR IN LH	TFR-03	D-MAX	Isuzu
8-97235078-3	PANEL; ROOF SIDE IN.R	TFR-03	D-MAX 03	Isuzu
8-97235107-3	PANEL; ROOF (S/C)	TFR-03	D-MAX SP/CAB	Isuzu
8-97235326-3	PANEL; ROOF (W/O HOLE)	TFR-03	D-MAX	Isuzu
8-97235330-3	PANEL; ROOF (SIN.W/HL)	TFR-03	D-MAX	Isuzu
8-97235457-1	COVER.MUD.FENDER.LH	TFR-03		Isuzu
8-97235460-0	COVER; MUD.FENDER RH.	TFS-03		Isuzu
8-97235460-1	COVER; MUD FENDER RH	TFS-03		Isuzu
8-97235462-0	COVER; MUD FENDER LH	TFS-03		Isuzu
8-97235784-0	BUSHING; RUBBER STAB	TFR-03	D-MAX	Isuzu
8-97235864-0	BAR; TORSION.FT.SUS.R	TFR-03		Isuzu
8-97235865-0	BAR; TORSION, FT.SUS.L	TFR-03		Isuzu
8-97235867-2	BAR; FRT.BUMPER	TFR-03	D-MAX	Isuzu
8-97235872-3	SUPPORT; FRT.BUMPER	TFR-03	D-MAX	Isuzu
8-97235874-0	DUCT; SIDE DEFROSTER	TFR-03	D-MAX	Isuzu
8-97235878-0	DUCT; SIDE DEFROSTER	TFR-03	D-MAX	Isuzu
8-97235879-2	BOOT; CHANGN LEVER	TFR-03		Isuzu
8-97235925-1	RUBBER; HELPER RR.	TFS-03		Isuzu
8-97235962-2	BUMPER; FT.D-GRAY 4X2	TFR-03	D-MAX	Isuzu
8-97235966-2	BUMPER; FT.D-GRAY 4X4	TFS-03	D-MAX 4X4	Isuzu
8-97236049-0	BRACKET; FRT.BUMPER	TFR-03	D-MAX	Isuzu
8-97236050-1	BRACKET; FRT.BUMPER	TFR-03	D-MAX	Isuzu
8-97236071-1	LOCK; DOOR FR.DOOR RH	TFR-03		Isuzu
8-97236072-1	LOCK; DOOR FR.DOOR LH	TFR-03		Isuzu
8-97236303-0	BUSHING; RUBBER S/ABS	TFR-03	D-MAX	Isuzu
8-97236313-6	PANEL; SIDE GATE RH.	TFR-03	D-MAX SINGLE	Isuzu
8-97236617-6	PANEL; SIDE GATE LH.	TFR-03	D-MAX	Isuzu
8-97236690-1	LAMP ASM; LICENSE PLA	TFR-03	D-MAX	Isuzu
8-97236793-1	REINFORC.BODY S/IN R	TFR-03	D-MAX	Isuzu
8-97236794-1	REINFORC.BODY S/IN.L	TFR-03	D-MAX	Isuzu
8-97237046-0	HORN; HIGH NOTE	TFR-03	D-MAX	Isuzu
8-97237378-1	LAMP; SIDE FLASHER	TFR-03	D-MAX	Isuzu

Part No	Part Names	Models		Brand
8-97238519-0	NOZZLE; W/SHIELD WASH	TFR-03	D-MAX	Isuzu
8-97238999-0	SEAL; OIL TRANSFER	TFR-05		Isuzu
8-97239342-0	MOLDING; W/S, UPR.	TFR-03	D-MAX	Isuzu
8-97239868-0	RETAINER RR AXLE	TFR-03	D-MAX	Isuzu
8-97240602-1	BAR; BACK, RR (ED)	TFR-03	D-MAX 05	Isuzu
8-97240603-1	BAR; BACK, RR (ED)	TFR-03	D-MAX 05	Isuzu
8-97240604-1	PAD; CENTER, BUMPER RR	TFR-03	D-MAX	Isuzu
8-97245069-0	SPRING; COIL FRT.A/T	TFR-03	D-MAX	Isuzu
8-97247083-0	BUSHING; RUBBER STAB	TFR-03	D-MAX	Isuzu
8-97249308-1	PNL; DASH SIDE INN, LH	UCR/S-05	UCR/S	Isuzu
8-97249541-1	RUBBER; CUSHION	TFR-03	D-MAX	Isuzu
8-97251393-0	COVER RELAY FUSE BOX	TFR-03	D-MAX	Isuzu
8-97251394-0	COVER RELAY FUSE BOX	TFR-03	D-MAX	Isuzu
8-97251395-0	BOX RELAY FUSE	TFR-03	D-MAX	Isuzu
8-97254387-0	RUBBER; SUB SPRING	NKNPNQ06		Isuzu
8-97255313-0	BLOCK; SHIFT, CL	NK/NP-06		Isuzu
8-97256547-0	SHAFT; STRG.2ND	TFR-03	D-MAX 4X2	Isuzu
8-97257598-0	PAD; PEDAL ACCEL	TFR-03		Isuzu
8-97263035-0	COVER ASM.IDLE CONT	TFR-03	D-MAX	Isuzu
8-97263052-0	GASKET; EXH.PIPE	TFR-03	D-MAX	Isuzu
8-97264184-0	BUSHING; RUBBER S/ABS	TFR-03	D-MAX	Isuzu
8-97287517-2	FILTER ASM; FUEL 4JA1	TFR-03	D-MAX	Isuzu
8-97287521-0	PIPE; INJ NO.1 4JA1	TFR-03	D-MAX	Isuzu
8-97287522-0	PIPE; INJ.NO.2 4JA1	TFR-03	D-MAX	Isuzu
8-97287523-0	PIPE; INJ.NO.3 4JA1	TFR-03	D-MAX	Isuzu
8-97287524-0	PIPE; INJ.NO.4 4JA1	TFR-03	D-MAX	Isuzu
8-97288271-2	PIPE; WATER OUT	TFR-03		Isuzu
8-97288947-0	FULE FILTER	TFR-2001	TFR 3.0	Isuzu
8-97289169-0	RUBBER; CUSHION EXH.	TFR-03	D-MAX	Isuzu
8-97293681-1	HANDLE; OUT DR.R (A/WH	TFS-03	D-MAX 4X4	Isuzu
8-97293684-1	HANDLE; OUT.DR.L (A/WH	TFS-03	D-MAX 4X4	Isuzu
8-97293687-3	MIRROR/D; RH. (A/WHT)E	TFR-03	D-MAX	Isuzu
8-97293696-3	MIRROR/D; LH. (A/WHT)E	TFR-03	D-MAX	Isuzu
8-97293997-1	HANDLE INSIDE FT.D R	TFR-03		Isuzu
8-97293998-1	HANDLE INSIDE FT.D L	TFR-03		Isuzu
8-97294070-2	LAMP ASM.ROOM	TFR-03	D-MAX	Isuzu
8-97296143-0	HANDLE OUTSIDE RR L	TF-CAB4		Isuzu
8-97298416-0	COVER; CONSOLE EX/SL	TFR-03		Isuzu
8-97298419-0	BOX; CONSOLE, LWR	TFR-03		Isuzu
8-97298421-0	COVER; CONSOLE SX/SLX	TFR-03		Isuzu
8-97298454-3	HANDLE; WINDOW REG.FR	TFR-03	D-MAX	Isuzu
8-97298455-2	COVER ASM; DOOR POC R	TFR-03		Isuzu
8-97298456-2	COVER ASM; DOOR POC L	TFR-03	D-MAX	Isuzu
8-97298466-0	CABLE ASM; IDLE CONT.	TFR-03		Isuzu
8-97299326-0	PANEL; INST	TFR-03	D-MAX 03	Isuzu
8-97300106-1	ARM; SHIFT HIGH-LOW	TFR-03		Isuzu
8-97300787-2	THERMOSTAT; 85 B	FRR-11		Isuzu
8-97300790-2	THERMOSTAT	FRR-11		Isuzu

Part No	Part Names	Models		Brand
8-97300948-0	SHAFT; TOP GEAR.TRANS	TFR-05	D-MAX	Isuzu
8-97301188-0	RETAINER; FT.BUMPER	TFR-03	D-MAX	Isuzu
8-97301256-0	MIRROR; ROOM	TFR-03	D-MAX	Isuzu
8-97301478-0	CYLINDER BRAKE RR	TFR-03	D-MAX 4X2	Isuzu
8-97301490-0	LEVER; PARKING BRK RH	TFR-03		Isuzu
8-97301491-0	LEVER; PARKING BRK RH	TFR-03		Isuzu
8-97301493-0	RETAINER PARKING BRK	TFR-03	D-MAX	Isuzu
8-97301502-0	SPRING; SHOE RET	TFR-03	D-MAX	Isuzu
8-97301503-0	LEVER; AUTO ADJ RH	TFR-03	D-MAX	Isuzu
8-97301504-0	LEVER; AUTO ADJ LH	TFR-03	D-MAX	Isuzu
8-97301509-0	PIN; SHOE HOLD DOWN	TFR-03	D-MAX	Isuzu
8-97301510-0	SPRING SHOE HOLD DOW	TFR-03	D-MAX	Isuzu
8-97301511-0	PIN; SHOE HOLD DOWN	TFR-03	D-MAX	Isuzu
8-97301519-0	LEVER; PARKING BRK RH	TFS-03		Isuzu
8-97301520-0	LEVER; PARKING BRK LH	TFS-03		Isuzu
8-97301523-0	SPRING; SHOW RET	TFS-03	D-MAX	Isuzu
8-97301524-0	SPRING; ADJ LEVER RH	TFS-03	D-MAX	Isuzu
8-97301525-0	SPRING; ADJ LEVER LH	TFS-03	D-MAX	Isuzu
8-97301527-0	ADJUSTER; RR BRK RH	TFS-03	D-MAX 4X4	Isuzu
8-97301528-0	ADJUSTER; RR.BRK LH	TFS-03	D-MAX 4X4	Isuzu
8-97301532-0	CYLINDER; BRK.MASTER	TFR-03	D-MAX	Isuzu
8-97301535-0	MASTER VAC ASM; BRK.	TFR-03	D-MAX	Isuzu
8-97301684-0	SWITCH; STOP LAM	TFR-03	D-MAX	Isuzu
8-97301688-0	BUSHING; CLU&BRK PEDA	TFR-03	D-MAX	Isuzu
8-97301795-1	PROTECTOR FRT DOOR	TFR-03	D-MAX	Isuzu
8-97301844-1	DECAL RR QUARTER	TFS-03		Isuzu
8-97301853-1	EMBLEM TAIL GATE	TFR-03	D-MAX	Isuzu
8-97301855-1	DECAL; TAIL GATE	TFS-03	D-MAX	Isuzu
8-97301857-1	DECAL; TAIL GATE	TFR-03	D-MAX	Isuzu
8-97301860-0	DECAL; "4WD" T/GATE	TFS-03	TFS D-MAX	Isuzu
8-97301998-1	CAP; WHL.5.5X14-41STL	TFR-03	D-MAX	Isuzu
8-97302184-1	STOPPER; TAILGATE LIN	TFR-03		Isuzu
8-97302185-2	STOPPER; TAILGATE	TFR-03		Isuzu
8-97302291-0	CLUTCH; COOLING FAN	TFR-03	D-MAX	Isuzu
8-97302635-1	BRAKE RR	TFR-03		Isuzu
8-97302636-1	BRAKE RR	TFR-03		Isuzu
8-97302637-1	BRAKE RR	TFR-03	D-MAX	Isuzu
8-97302810-0	BUSHING; RUBBER S/ABS	TFR-03	D-MAX 4X2	Isuzu
8-97304264-0	BOLT; CENTER LEAF SPR	TFR-03	D-MAX	Isuzu
8-97304853-0	REPAIR KIT; STRG.1YR.	TFS-03		Isuzu
8-97304903-0	ROD ASM.INNER	TFR-03	D-MAX	Isuzu
8-97304923-0	RUBBER MTG.PINION SI	TFR-03		Isuzu
8-97304928-0	ROD END; OUTER	TFR-03	D-MAX	Isuzu
8-97304936-0	RUBBER MTG.PINION SI	TFR-03		Isuzu
8-97305716-0	CAP; WHL.6.5X15-41STL	TFR-03	D-MAX	Isuzu
8-97306461-2	WATER OUTLET PIPE	TFR-03	D-MAX	Isuzu
8-97306533-5	PULLEY; CR/SHF 4JA1	TFR-03	D-MAX	Isuzu
8-97308614-1	FUEL TANK CAP	TFR-03	D-MAX	Isuzu

Part No	Part Names	Models	Brand
8-97308922-2	SILENCER ASM. EXH	TFR-03	Isuzu
8-97309012-4	LOCK ASM; TAIL	TFR-03 D-MAX SINGLECAB	Isuzu
8-97309292-0	RELAY DIMMER PASSING	TFR-03 D-MAX	Isuzu
8-97309294-0	RELAY; HEADLAMP	TFR-03 D-MAX	Isuzu
8-97309675-1	VALVE; INL	TFR-05 D-MAX 05	Isuzu
8-97309677-1	VALVE; EXHAUST 4JJ	TFR-05 D-MAX 05	Isuzu
8-97309927-0	OIL FILTER DMAX	TFR-03 D-MAX	Isuzu
8-97310064-1	HOSE; JOINT TANK	TFR-03 D-MAX	Isuzu
8-97310952-0	BULB; SIDE TURN 12V5W	TFR-03 D-MAX	Isuzu
8-97311632-1	CRANKSHAFT	TFR-05 D-MAX 05	Isuzu
8-97311876-0	BUFFER; ENG HOOD FRT.	TFR-03 D-MAX	Isuzu
8-97311928-2	PIN; PISTON	TFR-05 D-MAX 05	Isuzu
8-97311976-0	VALVE ASM	KBZNK KBZDI 87HP	Isuzu
8-97312108-1	SENSOR; CRANKSH	TFR-07 D-MAX 05	Isuzu
8-97312147-3	PUMP ASM; WATER	TF-05 D-MAX 05	Isuzu
8-97312147-4	PUMP ASM; WATER	TF-05 D-MAX 05	Isuzu
8-97312156-0	GASKET; PUMP TO	TFR-05 D-MAX 05	Isuzu
8-97312221-2	GASKET; GEAR CA	TFR-05 D-MAX 05	Isuzu
8-97312331-1	SPROCKET COMP, CHAR	NLR 08 D-MAX 05	Isuzu
8-97314204-0	SWITCH; TRANSFER INDI	TFR-03	Isuzu
8-97314350-0	MOTOR ASM.FT WASHER	TFR-03 D-MAX	Isuzu
8-97316591-0	BEARING; CLU RE	TFR-05	Isuzu
8-97318799-0	COVER CLU.PEDAL	TFR-03 D-MAX	Isuzu
8-97318963-0	FAN COOLING	TFR-03 D-MAX	Isuzu
8-97318963-1	FAN COOLING	TFR-07 D-MAX	Isuzu
8-97319300-0	CYLINDER; WHEEL	TFR-07	Isuzu
8-97319308-0	FASTENER; POP RIVET S	TFR-05	Isuzu
8-97319828-0	REPAIR KIT; BRK.M/CYL	TFR-03 D-MAX	Isuzu
8-97321273-0	RESISTOR; BLOWER UNIT	TFR-03 D-MAX	Isuzu
8-97322311-1	HOSE; VAC PUMP RETURN	TFR-03 D-MAX	Isuzu
8-97322311-2	HOSE; VAC PUMP RETURN	TFR-03	Isuzu
8-97323282-1	WHEEL; DISC 5.5X14-41	TFR-03	Isuzu
8-97323283-1	WHEEL; DISC 6.5X15-41	TFR-03 D-MAX	Isuzu
8-97323297-0	SEAL; OIL RR.AXLE	TFR-03 D-MAX	Isuzu
8-97323464-3	TAIL GATE ASM; (S/C)	TFR-03 D-MAX	Isuzu
8-97323465-2	T/G; SPARK W/HINGE	TFR-03 D-MAX SINGLE	Isuzu
8-97324669-1	WHEEL; DISC 16X7J-38	TFR-03 D-MAX	Isuzu
8-97326490-0	TANK VAC.BRK	TFR-03	Isuzu
8-97328642-4	CAMSHAFT; INL	TFR-05 D-MAX 05	Isuzu
8-97328644-6	CAMSHAFT; EXH	TFR-05 D-MAX 05	Isuzu
8-97328866-0	GASKET; CYL HD	TFR-05 D-MAX 05	Isuzu
8-97328867-1	GASKET; CYL HD	TFR-05 D-MAX	Isuzu
8-97328868-1	GASKET; CYL HD	TFR-05	Isuzu
8-97329621-0	PLUG; DRAIN, OIL	TFR-07 D-MAX 07	Isuzu
8-97329645-0	PIPE; EXH. (4X4)	TFR-03 D-MAX 4X4	Isuzu
8-97330454-0	HOSE; FLEX FRT.BRK, RH	TFR-03 D-MAX 4X4	Isuzu
8-97330511-0	RING SNAP	TFR-03 D-MAX	Isuzu
8-97330904-0	SEAL; OIL, LIP, A/T	TFS-05 D-MAX 05	Isuzu

Part No	Part Names	Models		Brand
8-97331457-0	GRILLE; RAD.GRAY PRIM	TFS-03	D-MAX 4X4	Isuzu
8-97331458-0	GRILLE; INNER.RAD	TFS-03	D-MAX	Isuzu
8-97331459-0	EMBLEM; RAD.GRILLE	TFR-03	D-MAX 4X4	Isuzu
8-97331613-0	GRILLE; RAD.BRIGHT-HD	TFS-03		Isuzu
8-97331844-0	RUBBER; FT.MUDGUARD R	TFS-03	D-MAX 4X4	Isuzu
8-97331845-0	RUBBER; FT.MUDGUARD L	TFS-03	D-MAX	Isuzu
8-97331851-1	EXTENT; F.BPR.RH (PRIM	TFR-05	D-MAX 05	Isuzu
8-97331852-1	EXTENSION; FRT	TFR-05	D-MAX 05	Isuzu
8-97331862-1	W/RETAINER	TFR-03	D-MAX	Isuzu
8-97331863-1	PROTECTOR WHEEL FT.L	TFR-03	D-MAX	Isuzu
8-97332380-0	PLUG; SOCKET HEADLAMP	TFR-03	D-MAX	Isuzu
8-97332448-0	COVER; BULB HEADLAMP	TFR-03		Isuzu
8-97332642-0	BUSHING; LEAF SPR, RR	TFR-03	D-MAX	Isuzu
8-97333108-0	NUT; WHEELFT (STEEL)	TFR-03	D-MAX	Isuzu
8-97333142-0	LEVER; ENG.HOOD	TFR-03	D-MAX	Isuzu
8-97333143-0	CABLE; ENG HOOD CONT	TFR-03	D-MAX	Isuzu
8-97333143-2	CABLE; ENG HOOD	TFR-03	D-MAX	Isuzu
8-97333319-0	RUBBER; MTG, CONDENSER	TFR-03	D-MAX	Isuzu
8-97333348-0	GUIDE; FAN	TFR-03	D-MAX	Isuzu
8-97333348-1	GUIDE; FAN	TFR-03	D-MAX	Isuzu
8-97333350-3	RADIATOR ASM; M/T 4JH	TFR-03	D-MAX	Isuzu
8-97333354-0	CAP; SURGE TANK	TFR-03	D-MAX	Isuzu
8-97333414-0	UNIT; FOG LAMP RH	TFR-03		Isuzu
8-97333415-0	UNIT; FOG LOAMP L	TFR-03		Isuzu
8-97349827-0	CAP; OIL TANK	TFR-03		Isuzu
8-97349900-0	BLADE; WIPER RH.550MM	TFR-03		Isuzu
8-97349903-0	BLADE; WIPER LH.475MM	TFR-03	D-MAX	Isuzu
8-97349905-0	CAP; WASHER	TFR-03	D-MAX	Isuzu
8-97349940-0	LOCK ASM; STRG.	TFR-03	D-MAX	Isuzu
8-97349946-0	COLUMN; STRG. (TILT)	TFR-03		Isuzu
8-97349981-0	LEN SIDE MIRROR LH	TFR-03	D-MAX	Isuzu
8-97349982-0	LEN SIDE MIRROR RH	TFR-03	D-MAX	Isuzu
8-97349993-A	ACTUATOR; DR, LK, FR.LH		D-MAX	Isuzu
8-97350478-1	ARD; MUD, RR/R	TFR-05		Isuzu
8-97350479-1	SLAP GUARD LH RR CRE	TFR-05		Isuzu
8-97351081-0	ACTUATOR; RR.DOOR, LH	TFR-03	D-MAX	Isuzu
8-97351082-0	ACTUATOR; RR.DOOR, RH	TFR-03	D-MAX	Isuzu
8-97351833-0	PLATE ASM; PRESS	NK/NQ-06	NPR120HP	Isuzu
8-97351919-0	SHOE; BRK, RR.RH	TFS-03	D-MAX 4 1pr๑๓	Isuzu
8-97351919-1	SHOE; BRK, RR.RH	TFS-03	D-MAX 4 1pr๑๓	Isuzu
8-97351920-0	SHOE; BRK, RR.LH	TFS-03	D-MAX 4 1pr๑๓	Isuzu
8-97351920-1	SHOE; BRK, RR.LH	TFS-03	D-MAX 4 1pr๑๓	Isuzu
8-97351921-0	SHOE; BRK, RR	TFS-03	D-MAX 4 1pr๑๓	Isuzu
8-97351921-1	SHOE; BRK, RR	TFS-03		Isuzu
8-97351934-0	BRACE BUMPER		C-193	Isuzu
8-97352581-0	BUMPER	TFR-03	D-MAX 05	Isuzu
8-97352582-0	BUMPER			Isuzu
8-97352583-0	BRACE; RR BUMPER	TFR-03	D-MAX	Isuzu

Part No	Part Names	Models		Brand
8-97352584-1	CASE; LOCK CYLINDER	TFR-05	D-MAX 05	Isuzu
8-97352585-2	CAP; LOCK CYLINDER	TFR-05		Isuzu
8-97352591-0	BOLT; BACK BAR	TFR-05	D-MAX 05	Isuzu
8-97352592-0	BOLT; BRKT	TFR-05	D-MAX 05	Isuzu
8-97352593-0	BOLT; BRACE	TFR-05	D-MAX 05	Isuzu
8-97352594-0	RIVET	TFR-05	D-MAX 05	Isuzu
8-97354055-1	SHAFT	TFR-05	D-MAX 05	Isuzu
8-97354887-0	BOLT; TORSION BAR, HE	TFR-05		Isuzu
8-97355476-0	FOOT; ENG	TFR-05		Isuzu
8-97355478-1	FOOT; ENG	TFR-05		Isuzu
8-97355671-2	PISTON	TFR-05	D-MAX 06	Isuzu
8-97355672-2	PISTON; CYL.GRD-B 4JK	TFR-05	D-MAX 05	Isuzu
8-97355870-0	CYLINDER ASM; BRK MA	TFR-05	D-MAX 05	Isuzu
8-97356541-0	PANEL; SIDE GATE LH	TFR-03	D-MAX CAB4	Isuzu
8-97356542-0	PANEL; SIDE GAT	TFR-03	D-MAX CAB-4	Isuzu
8-97356646-0	MOTOR ASM.FAN	UCR/S-05	UCR/S	Isuzu
8-97356711-2	GASKET; EGR VLV	TFR-05	D-MAX 05	Isuzu
8-97357492-0	BUSHING; SHACKLE, RR	TFR/S 97		Isuzu
8-97357524-1	DOOR ASM; REAR	UCR/S510	MU-7	Isuzu
8-97357713-0	REPAIR KIT; BRK, M/CYL	TFR-05		Isuzu
8-97357716-1	ROD ASM.CONN	TFR 03	D-MAX 05	Isuzu
8-97357716-3	ROD ASM.CONN	TFR-05	D-MAX 05	Isuzu
8-97357859-0	MIRROR ASM; DOOR LH	TFR-03	D-MAX 03	Isuzu
8-97357859-1	MIRROR ASM; DOOR LH	TFR-10.5	D-MAX 03	Isuzu
8-97357860-0	MIRROR ASM; DOOR	TFR-03	D-MAX 03	Isuzu
8-97357860-1	MIRROR ASM; DOOR	TFR-10.5	D-MAX 03	Isuzu
8-97357870-0	MIRROR ASM; DOOR LH	TFR-05	D-MAX	Isuzu
8-97357871-0	MIRROR ASM; DOOR	TFR-05		Isuzu
8-97357924-0	PAD; STEP, RR BUMPER R	TFR-03	D-MAX	Isuzu
8-97357925-0	PAD; STEP, RR BUMPER L	TFR-03	D-MAX	Isuzu
8-97358245-0	SLEEVE; HIGH-LOW SHF	TFR-05	D-MAX 05	Isuzu
8-97358315-0	SWITCH; ACCEL	NPNQ 06	NPR 2005	Isuzu
8-97358720-0	OIL FILTER	TFR-05	D-MAX 05	Isuzu
8-97359170-0	DOOR ASM; RR.RH	TFR-CAB4	D-MAX CAB4	Isuzu
8-97359171-0	DOOR ASM; REAR LH	TFR-CAB4	D-MAX	Isuzu
8-97360093-0	CABLE; ENG.CONT 4JH1	TFR-03	D-MAX	Isuzu
8-97360482-5	PANEL; QUARTER	UCR/S510	UCR 10	Isuzu
8-97360483-5	PANEL; QUARTER	UCR-10.5	UCR 10	Isuzu
8-97360505-0	DRUM; BRK, RR 4X2	TFR-03	D-MAX 4X2	Isuzu
8-97360600-0	HINGE ASM; RR GATE RH	TFR-03	D-MAX	Isuzu
8-97360602-0	HINGE ASM; RR GATE LH	TFR-03	D-MAX	Isuzu
8-97360677-0	ROTOR; DISC BRK FT 4W	TFS-03	D-MAX 4X4	Isuzu
8-97360680-0	SW.COMB (WIPER, -AIR/B	TFR-03	D-MAX	Isuzu
8-97361321-0	INSULATOR; ENG HOOD	TFR-03	D-MAX	Isuzu
8-97361477-0	GRILLE; AIR OUTLET	TFR-05	D-MAX 05	Isuzu
8-97361562-1	PULLEY; CR/SHF	TFR-05	D-MAX 05	Isuzu
8-97362215-2	PULLEY; FAN DRI	TFR-05	D-MAX 05	Isuzu
8-97362229-0	STAY; ENG HOOD FRT EN	TFR-03	D-MAX	Isuzu

Part No	Part Names	Models	Brand
8-97362926-0	BELT; COOLING FAN=1600	TFR-05	Isuzu
8-97362955-0	HOSE; RAD TO SURGE TA	TFR-03	Isuzu
8-97363009-0	LOCK; ENG HOOD	TFR-08	D-MAX 08
8-97363357-0	CABLE; A/T	TFR-03	D-MAX
8-97363448-0	BEZEL; FOG LAMP	TFR-03	Isuzu
8-97363449-0	BEZEL; FOG LAMP LH.	TFR-03	Isuzu
8-97363521-1	ABSORBER ASM; S	UCR/S510	UCR/S 04
8-97363543-0	RUBBER SUPPORT E.	TFR-05	D-MAX 05
8-97363604-0	HOSE; WATER , RAD.INL.	TFR-05	D-MAX 05
8-97363604-1	HOSE; WATER , RAD.INL.	TFR-05	Isuzu
8-97363605-0	HOSE; WATER, RAD	TFR-05	D-MAX 05
8-97363605-1	HOSE; WATER, RAD	TFR-05	Isuzu
8-97363805-0	HOSE; FLEX, FRT BRK	TFR-03	D-MAX
8-97363871-3	PANEL; TAIL GATE	UCR/S510	UCR/S 03-05
8-97364114-0	LAMP ASM; RR CO	TFR-05	Isuzu
8-97364115-0	LAMP ASM; RR CO	TFR-05	Isuzu
8-97364173-0	BUSHING; UPR LINK, FR	TFR-03	D-MAX
8-97364174-0	BUSHING; LWR LINK	TFR-03	D-MAX
8-97364175-0	BUSHING; UPR LINK, FRT	TFS-03	D-MAX
8-97364176-0	BUSHING; LWR LINK	TFS-03	Isuzu
8-97364177-0	BUSHING; LWR LINK	TFS-03	Isuzu
8-97364302-1	PANEL; DEFLECTO	TFR-05	D-MAX 05
8-97364801-0	LAMP ASM; HEAD RH.	TFR-03	D-MAX
8-97364802-0	LAMP ASM; HEAD LH.	TFR-03	D-MAX
8-97365054-0	WHEEL; DISC, AL	TFR-03	Isuzu
8-97365055-0	WHEEL; ALLOY 7X16-38	TFS-03	Isuzu
8-97365219-0	BOLT; RUBBER	TFR-03	D-MAX
8-97365220-0	BOLT; RUBBER	TFR-03	D-MAX
8-97365654-0	FORK (8-97039266-0)	TFR-07	KBZDI 87HP
8-97365743-0	SENSOR; VIHIC SPD MT	TFR 97	Isuzu
8-97365932-0	NUT; WHEEL, FRT AXLE	TFR-03	D-MAX
8-97365974-0	DOOR; FRT, W/O TRIM LH	TFR-03	D-MAX
8-97366523-0	DOOR ASM; FRT.RH	TFR-03	D-MAX CAB 4
8-97366524-0	DOOR ASM; FRT, W	TFR-03	D-MAX CAB4
8-97366938-0	PANEL; DEFLECT (-ED)	TFR-03	D-MAX
8-97367044-0	BAR; FRT BUMPER	TFR-05	D-MAX 05
8-97367272-0	RUBBER; ENG FOOT.FR.R	TFR-03	D-MAX
8-97367273-0	RUBBER; SUPPORT ENG.	TFR-03	D-MAX
8-97367285-0	RUBBER; CUSHION MTG#1	TFR-03	D-MAX
8-97367286-0	RUBBER; CUSHION CAB	TFR-03	D-MAX
8-97367287-0	RUBBER; CUSHION CAB	TFR-03	D-MAX
8-97367363-3	GRILLE; INNER.RAD	TFS-05	Isuzu
8-97367959-0	ACTUAL; AXLE (4X4)	TFR-03	Isuzu
8-97368828-4	CLEANER ASM; AI	TFR-05	D-MAX 05
8-97369017-0	CHECK ARM; DOOR REAR	TFR-CAB4	Isuzu
8-97369560-0	CAP FUEL INNER	TFR-03	D-MAX D/CAB
8-97370515-0	BRAKE DRUM; FRT.	TFR-05	D-MAX
8-97371385-0	SEAL; BACKLIGHT GLASS	TFR-05	D-MAX 05

Part No	Part Names	Models		Brand
8-97371447-2	GUIDE FAN	TFR-05	D-MAX 05	Isuzu
8-97371734-0	KNOB; CHANGE LE	TFR06UC		Isuzu
8-97372286-0	ABSORBER ASM; S	TFR-04	D-MAX 04	Isuzu
8-97372419-1	CRANKSHAFT	TFR-05	D-MAX 05	Isuzu
8-97372866-1	SHROUD; FAN	TFR-05	D-MAX 05	Isuzu
8-97373555-0	SEAL OIL OUT PU	TFS/UBS		Isuzu
8-97373636-0	TANK ASM; WASHE	UCR/S510		Isuzu
8-97373838-0	MOTOR ASM; FRT	UCR/S 05	UCR/S 07	Isuzu
8-97373873-0	DAMPER; DYNAMIC	TFR-05	D-MAX 05	Isuzu
8-97374294-0	CABLE; PARKING	TFR-05		Isuzu
8-97374661-1	LAMP ASM; FOG	TFR-07	D-MAX 07	Isuzu
8-97374697-0	CAP; WHEEL	TFR-05	D-MAX 05	Isuzu
8-97375606-2	LAMP ASM; RR CO	TFR-07	D-MAX 07	Isuzu
8-97375607-2	LAMP ASM; RR CO	TFR-07	D-MAX 07	Isuzu
8-97377370-0	8-97331839-0	TFR-05	D-MAX 4X4	Isuzu
8-97377371-0	M/D; WHEEL ARCH RR.LH	TFR-05	D-MAX 4X4	Isuzu
8-97377373-0	MOLDING; WHEEL	UCR/S-05		Isuzu
8-97377374-0	MOLDING; WHEEL	UCR/S-05	UCS/S5	Isuzu
8-97377499-0	M/WHEEL; ARCH RR R CR	TFR-05		Isuzu
8-97377503-0	MOLDING; WHEEL	TFR-06	D-MAX 06	Isuzu
8-97377504-0	MOLDING; WHEEL	TFR-06		Isuzu
8-97377920-0	SENSOR; VEHICLE	TFR-05		Isuzu
8-97378485-0	DECAL; RR END	TFR-05	D-MAX 05	Isuzu
8-97379691-1	CABLE; PARKING	UCR/S-05		Isuzu
8-97379692-1	CABLE; PARKING	UCR/S-05	UCR	Isuzu
8-97381456-0	8-98017270-0 Local	NKR501	NKR 110HP	Isuzu
8-97381465-0	SWITCH; PRESSUR	UCR/S510	UCR/S	Isuzu
8-97381629-0	LAMP; STOP HIGHMOUNT	TFR-05	D-MAX 05	Isuzu
8-97386725-0	GUARD; MUD, RR	TFR-03	D-MAX	Isuzu
8-97386726-0	GUARD; MUD, RR	TFR-03	D-MAX	Isuzu
8-97386727-0	GUARD; MUD, RR	TFR-03	D-MAX	Isuzu
8-97386728-0	FLAP; REAR MUD.L	TFR-03	D-MAX	Isuzu
8-97387304-0	PANEL; SIDE OUTER RH C	TFR-07	D-MAX 07	Isuzu
8-97387309-0	PANEL; SIDE OUTER LH	TFR-07	D-MAX 07 CAB-4	Isuzu
8-97387310-0	PANEL; SIDE OUTER	TFS-07	D-MAX 07	Isuzu
8-97387311-0	PANEL; SIDE OUTER	TFS-07	D-MAX 07	Isuzu
8-97387332-0	PANEL; SIDE OUTER	TFR-07	D-MAX 07 4X2	Isuzu
8-97387333-0	PANEL; SIDE OUTER	TFR-07	D-MAX 07 4X2	Isuzu
8-97387361-0	FENDER; FRT	TFR-07	D-MAX 07 EX	Isuzu
8-97387362-0	FENDER; FRT	TFR-07	D-MAX 07	Isuzu
8-97387363-0	FENDER; FRT	UCR/S-07	UCR/S 07	Isuzu
8-97387364-0	FENDER; FRT	UCR/S-07	UCR/S 07	Isuzu
8-97387367-0	FENDER; FRT	TFR-07	D-MAX 07 RODEO	Isuzu
8-97387367-1	FENDER; FRT	TFR-10.5	D-MAX 07 RODEO	Isuzu
8-97387368-0	FENDER; FRT	TFR-07	D-MAX 07 RODEO	Isuzu
8-97387369-1	FENDER; FRT	TFR-10.5	D-MAX 07 SL SX	Isuzu
8-97387370-0	FENDER; FRT	TFR-07	D-MAX 07 SL SX	Isuzu
8-97387371-0	FENDER; FRT	TFR-07	D-MAX 07 RODEO	Isuzu

Part No	Part Names	Models		Brand
8-97387371-1	FENDER; FRT	TFR-10.5	D-MAX 07 LS	Isuzu
8-97387373-0	FENDER; FRT	TFR-07	D-MAX 07 RODEO	Isuzu
8-97387374-0	FENDER; FRT	TFR-07	D-MAX 07 SLX	Isuzu
8-97387375-0	FENDER; FRT	TFR-07	D-MAX 07 SLX	Isuzu
8-97387378-0	TAIL GATE	TFR-07	D-MAX 07	Isuzu
8-97387380-0	PANEL; DEFLECTO	TFR-07		Isuzu
8-97387477-0	BOOT KIT; IN SI	TFR-06	D-MAX 06	Isuzu
8-97387478-0	BOOT KIT; OUTSI	TFR-06	D-MAX 06	Isuzu
8-97387663-0	JOINT ASM	TFR-06	D-MAX05	Isuzu
8-97387664-0	JOINT ASM; OUTS	TFR-06		Isuzu
8-97387674-0	SHAFT ASM; FRT	TFR-06	D-MAX 07	Isuzu
8-97387674-1	SHAFT ASM; FRT	TFR-06	D-MAX 07	Isuzu
8-97387956-0	BUMPER; RR	UCR/S510		Isuzu
8-97387989-0	SENSOR;	TFR-07	D-MAX 07	Isuzu
8-97387990-1	SENSOR; SPD, FRT	TFR-07		Isuzu
8-97387992-0	SENSOR;	TFR-07	D-MAX 07	Isuzu
8-97387992-1	SENSOR; SPD, RR	TFR-07	D-MAX 07	Isuzu
8-97388502-A	MATAL; SET C/S		D-MAX 05	Isuzu
8-97388503-1	MATAL; SET C/S	TFR-05	D-,MAX 05	Isuzu
8-97388504-0	MATAL; SET C/S	TFR-05	D-MAX 05	Isuzu
8-97388505-3	MATAL; SET C/S	TFR-05	D-MAX 05	Isuzu
8-97388506-4	MATAL; SET C/S	TFR-05	D-MAX 05	Isuzu
8-97388735-0	MATAL; SET C/S	TFR-05	D-MAX 05	Isuzu
8-97388934-0	MOLDING; WHEEL	UCR/S510	UCR/S510	Isuzu
8-97388936-0	MOLDING; WHEEL	UCR/S510		Isuzu
8-97388937-0	MOLDING; WHEEL	UCR/S510		Isuzu
8-97393882-0	FINISHER FENDER MOLD	TFR-03	D-MAX	Isuzu
8-97393892-0	FINISHER; FRT.BUMPER	TFR-03	D-MAX	Isuzu
8-97394455-0	LID ASM.RR.CONSOLE	TFR-CAB4	TFR CAB4	Isuzu
8-97395013-0	COVER; RECLINING RH	TFR-03		Isuzu
8-97395014-0	COVER; RECLINING LH	TFR-03		Isuzu
8-97396033-0	FINISHER; FR (L/GRAY40	TFR-05	D-MAX 05	Isuzu
8-97396084-0	LAMP ASM; SPOT	TFR-03	D-MAX	Isuzu
8-97396181-0	MIRROR ASM; DOO	TFR-05	D-MAX 07	Isuzu
8-97396182-0	MIRROR ASM; DOO	TFR-05		Isuzu
8-97396183-0	DOOR MIRROR RH	TFR-05	D-MAX 07	Isuzu
8-97396250-0	CLUSTER; INST CENTER	TFR-03		Isuzu
8-97396253-0	GRILLE; SIDE, AI	TFR-05		Isuzu
8-97397845-0	AIR BAG UNIT; DRIVER	TFR-03	D-MAX	Isuzu
8-97397853-0	FINISHER; FENDE	TFR-05	D-MAX 05	Isuzu
8-97398205-0	BOX; CONSOLE, UPR	TFR-03	D-MAX	Isuzu
8-97400032-0	DOOR HANDLE RR OUTER	UCR/S510		Isuzu
8-97400391-0	SWITCH; PWR WD RH	TFR-05		Isuzu
8-97400392-0	SWITCH; PWR WD LH	TFR-CAB4	D-MAX	Isuzu
8-97400394-0	SWITCH; PWR WD RH	TFR-CAB4	TFR CAB4	Isuzu
8-97400753-0	SWITCH; POWER W	TFR-07		Isuzu
8-97400754-0	SWITCH; POWER W	TFR-07		Isuzu
8-97403299-0	TRAY ASM; ASH	TFR-07	D-MAX 07	Isuzu

Part No	Part Names	Models		Brand
8-97403311-2	BOX; CONSOLE, UP	TFR-07	D-MAX07	Isuzu
8-97403475-1	SUN VISOR	TFR/S-07		Isuzu
8-97403484-3	SUN VISOR	TFR/S-07		Isuzu
8-97403688-1	STEERING WHEEL	TFR-07	D-MAX 07	Isuzu
8-97403704-0	TRIM, FR DOOR RH	TFR-07	D-MAX 07	Isuzu
8-97403705-0	TRIM, FR DOOR LH	TFR-07	D-MAX 07	Isuzu
8-97403710-0	TRIM, FR DOOR	TFR-07	D-MAX 07	Isuzu
8-97403711-0	TRIM, FR DOOR	TFR-07	D-MAX 07	Isuzu
8-97403896-0	SWITCH; POWER W	TFR-07		Isuzu
8-97403897-0	SWITCH; POWER W	TFR-07	D-MAX 07	Isuzu
8-97403900-2	STEERING WHEEL LEATHER	TFR-07		Isuzu
8-97404937-0	PANEL; DOOR RR RH LH	TFR-07	D-MAX 07	Isuzu
8-97404945-0	LID ASM.RR.CONSOLE	TFR-07	D-MAX 07	Isuzu
8-97406182-0	KNOB; CHANGE LE	TFR-07	D-MAX 07	Isuzu
8-97406184-0	KNOB; CHANGE LE	TFR-07		Isuzu
8-97408049-0	COVER FUSE BOX	TFR-07		Isuzu
8-97408066-0	HANDLE; WINDOW REG.FR	TFR-08	D-MAX	Isuzu
8-97408101-0	HANDLE; OUTSIDE FR OUTER	TFR-08		Isuzu
8-97408114-0	HANDLE; OUTSIDE FR OUTER	TFS-03		Isuzu
8-97408116-0	HANDLE; OUTSIDE FR OUTER	TFR-08		Isuzu
8-97408305-0	HANDLE	TFR/S-07		Isuzu
8-97408871-0	PAD; TRIM, DASH SIDE	TFR-07		Isuzu
8-97408903-0	AIR BAG UNIT; LH.	TFR-07	D-MAX	Isuzu
8-97418298-0	AIR BAG RH	TFR-07	D-MAX 07	Isuzu
8-97422062-0	AIR BAG LH	TFR-07	D-MAX 2007	Isuzu
8-97601967-0	SENSOR; MANIF	TFR-07	D-MAX	Isuzu
8-97604916-0	GASKET; SLEEVE,	FRR-11		Isuzu
8-97605228-0	GASKET; CYL HD	FTR 00		Isuzu
8-97855131-A	LENS FRT COMB:L	NK/NP 95	NKR 110HP	Isuzu
8-97859996-A	PLATE; STEP, RH	NP/NK 95	NPR120 HP	Isuzu
8-97859997-A	PLATE; STEP, LH	NP/NK 95	NPR120 HP	Isuzu
8-97910065-0	HOSE/R BY PASS +4JB1	TFR/S 97	TFR 2.8T	Isuzu
8-97910201-0	WATER OUTLET PIPE	TFR/S 97	TFR 2800	Isuzu
8-97910219-0	BELT; COOL B1027 (MBT)	TFR	TFR 87HP	Isuzu
8-97910227-0	L/SPRING ASSY	NKR-06	NKR55E	Isuzu
8-97910303-1	LAMP COMB; RR.RH.	TFR/S 97	TFR 97 2.5T	Isuzu
8-97910304-1	LAMP COMB; RR.LH.	TFR/S 97	TFR 97 2.5T	Isuzu
8-97910307-1	HEADLAMP; HALOGEN RH.	TFR/S 97	SPACE CAB	Isuzu
8-97910308-1	HEADLAMP; HALOGEN LH.	TFR/S 97	SPACE CAB	Isuzu
8-97910309-1	LAMP ASM CLEAR; RH	TFR/S 97	S-CAB	Isuzu
8-97910309-2	LAMP CLEARANCE RH.	TFR/S 97	S-CAB	Isuzu
8-97910310-2	LAMP; CLEARANCE LH.	TFR/S 97	S-CAB	Isuzu
8-97910333-0	NUT; WHEEL +SLX	TFR 97	TFR 97	Isuzu
8-97910437-0	1ST CROSS MEMBER ASS	TFR 97	TFR 87HP	Isuzu
8-97910647-1	INNER LINER; FEND RH	TFR 97	S-CAB	Isuzu
8-97910648-1	INNER LINER; FEND LH	TFR 97	S-CAB	Isuzu
8-97910693-4	H/BRAKE CBL; RR.RH	TFS 97	TFS 97	Isuzu
8-97910999-0	W/STRIP B.LIGHT	TFR*		Isuzu

Part No	Part Names	Models		Brand
8-97911026-0	CAB MTG R; NO.2, RH.	TFR/S 97		Isuzu
8-97911047-0	HANDLE; W/REGULATOR	TFR 96	TFR	Isuzu
8-97911085-0	RUBBER; FRT BUMPER	TFR	TFR 87HP	Isuzu
8-97911086-0	REBOUND RUBBER	TFS 97	TFS 97	Isuzu
8-97911087-0	REBOUND RUBBER	TFR	TFR 87HP	Isuzu
8-97911088-0	BUSH; STRUT BAR	TFR 97		Isuzu
8-97911090-0	HUB; FRT AXLE DI	TFR	TFR 87HP	Isuzu
8-97911091-0	ROTOR; DISC BRAC	TFR/S	TFR 87HP	Isuzu
8-97911092-0	HUB FRT. WHEEL	UCS 98	TFS 97	Isuzu
8-97911092-2	HUB FRT. WHEEL	UCS 98	TFS 97	Isuzu
8-97911097-1	SHOCK ABS.FRT.	TFR	TFR 87HP	Isuzu
8-97911098-0	STABILIZER BAR	TFS*	TFS	Isuzu
8-97911116-S	U-BOLT L=186	TFS 97	TFS 97	Isuzu
8-97911117-0	RUBBER HELP; RR S	TFS 97		Isuzu
8-97911118-0	RUBBER HELP; RR S*	TFR 97		Isuzu
8-97911254-0	H/B CABLE FT/LW	TFR	TFR 87HP	Isuzu
8-97911266-0	RUBBER SUPP E/MTG RR	TFR 97	TFS 2.8T	Isuzu
8-97911267-1	RUB.SUPPORT E/MTG RR	TFR 97		Isuzu
8-97911268-0	RUBBER SUPP.E/MTG RR	TFR 97	TFR 2.8T	Isuzu
8-97911300-1	SHOCK ABS.RR. (4X4)	TFS	TFS	Isuzu
8-97911311-0	WHEEL NUT	TFR	KBZDI 87HP	Isuzu
8-97911452-0	MIRROR/D.BLACK, RH	TFR/S 97	TFR 87HP	Isuzu
8-97911453-0	MIRROR/D.BLACK, LH.	TFR/S 97	TFR 87HP	Isuzu
8-97911489-0	GEAR; INJ.PUMP	TFR 97	TFR 97 2.5	Isuzu
8-97911697-1	RRᄁ SINGLE	TFR*	TFR 87HP SINGLE	Isuzu
8-97912087-0	CABLE; H/B.RR.LH.	TFR	TFR 87HP	Isuzu
8-97912530-0	PLUG; OIL DRAIN	TFR 02	TFR	Isuzu
8-97912531-0	GASKET, OIL DRAIN	TFR	TFR 87HP D-MAX	Isuzu
8-97912540-0	VALVE ASM	TFR-03		Isuzu
8-97912543-0	CAP; OIL FILLER	TFR		Isuzu
8-97912548-0	GASKET; OIL FILT	TFR 2001	TL 75HP	Isuzu
8-97912594-0	BELT; COOLING FA	TFR	TFR 87HP	Isuzu
8-97912615-0	GASKET; NOZZLE HOLDER	TFR/S 97	TFR 97	Isuzu
8-97912697-0	GASKET; TURBO CG	TFR 97	TFR 3.0	Isuzu
8-97912706-0	PIPE OIL P/COOL+4JB1	TFR/S 97	TFS 97	Isuzu
8-97912722-0	GAUGE; OIL LEVEL 4JA	TFR/S 97	TFR 97	Isuzu
8-97912740-0	HOSE RUBBER PVC	TFR/S 97		Isuzu
8-97912741-0	PACKING; HEAD COVER	TFR/S 97	KBZDI 87HP	Isuzu
8-97912750-1	IDLE GEAR	TFR/S 97	TFR 97 2.5	Isuzu
8-97912866-0	BRAKE DRUM: RR	TFR*	KBZ 85HP	Isuzu
8-97913465-0	SEAL DOOR OUTER RH	UCS 98	TFR	Isuzu
8-97913466-0	SEAL DOOR OUTER LH	UCS 98	TFR	Isuzu
8-97913558-0	BOLT	TFR-2000	D-MAX	Isuzu
8-97913879-0	RUBBER BUSH	TFS-2001	TFS 2000	Isuzu
8-97913910-2	LAMP; COMB.FRT.RH	TFR 98	SLX	Isuzu
8-97914323-0	BULB; HALOGEN 60/55W	TFR	D-MAX	Isuzu
8-97915230-0	LEVER ASM:INSIDE (RH)	TFR-98.5	TFR 97	Isuzu
8-97915231-0	LEVER:INSIDE (LH)	TFR-98.5	TFR 97	Isuzu

Part No	Part Names	Models		Brand
8-97915365-0	CABLE; H/B.RR.RH.	TFR	TFR 87HP	Isuzu
8-97915415-0	CLUSTER ASM; METER	TFR-98.5	TFR 97	Isuzu
8-97915721-0	WHEEL; DISC (SILVER)14	TFR-EX00	TFR	Isuzu
8-97915732-1	FENDER; FRT.RH	TFR 97	TFR 2.5T	Isuzu
8-97915817-0	ARM; HEIGHT CONT	TFR-2000	TFR 2000	Isuzu
8-97915832-0	BOLT; ; ADJ ROCKER	TFR-03	D-MAX 05	Isuzu
8-97915833-0	SHAFT ROCKER ARM	TFR-03	D-MAX	Isuzu
8-97916330-0	RUBBER; ENG.RH.FRT	TFR/S 97	TFR 2.5T	Isuzu
8-97916331-0	RUBBER; ENG.FRT.	TFR/S 97	TFR 2.5T	Isuzu
8-97916628-0	DRUM; PARKING BRAKE	NPR59	NPR66 120HP	Isuzu
8-97916700-0	THERMOSTAT HOUSING	TFR/S 97		Isuzu
8-97916740-0	RUBBER; MTG UPR	NPR(4HF)	NPR120HP	Isuzu
8-97916779-0	BRAKE DRUM PARKING	NKR-133	NKR130	Isuzu
8-97916993-1	FUEL FILTER	TFR-03	D-MAX	Isuzu
8-97917419-0	HEADLAMP; RH.MR. (BLK)	TFR 98	SLX	Isuzu
8-97917420-0	HEADLAMP LH.MR. (BLK)	TFR 98	SLX	Isuzu
8-97918052-2	LAMP; COMB.FRT.LH	TFR 98	SLX	Isuzu
8-97918412-0	LEVER ASM.ENG.HOOD	TFR-2000	TFR 2000	Isuzu
8-97918504-2	LAMP COMB; RR.WHT.RH.	TFR 2000	SPARK EX EXL	Isuzu
8-97918505-0	LAMP COMB RR; WHT.LH.	TFR 2000	SPARK EX EXL	Isuzu
8-97918505-2	LAMP COMB; RR.WHT.LH.	TFR 2000	SPARK EX EXL	Isuzu
8-97918839-0	GASKET SET; OVH.4JA1	TFR 95	TFR 87HP	Isuzu
8-97920007-0	SHAFT; IDLE GEAR A	TFR 01	TFR 2001	Isuzu
8-97920346-0	GASKET; GEAR CASE 4JH	TFR 01	TFR 01	Isuzu
8-97920346-1	GASKET; GEAR CASE 4JH	TFR 01	TFR 01	Isuzu
8-97920514-1	GASKET; INL MAN	TFR 01	4JH1	Isuzu
8-97921229-0	SEAL; VALVE GUIDE	TFR 02	D-MAX	Isuzu
8-97921857-0	FAN COLLING	TFR-03	TFR	Isuzu
8-97921857-1	FAN COLLING	TFR-03	TFR	Isuzu
8-97922137-0	PULLEY FAN DRIVE	TFR-03		Isuzu
8-97922552-1	BEARING; PILOP TOP GE	TFR-08	D-MAX	Isuzu
8-97923923-0	PIPE; WATER TURBO	TFR-2001	TFR 2000	Isuzu
8-97923924-0	PIPE; WATER TURBO	TFR-2001	TFR 2000	Isuzu
8-97940024-0	VALVE; INLET (4JA	TFR	TFR 2.5T	Isuzu
8-97940025-0	VALVE; INLET (4JA	TFR	TFR 2.5T	Isuzu
8-97940140-1	HOSE; V/P-CRANK CA.	TFR/S 97	TFR 97	Isuzu
8-97940157-0	WATER PUMP ASM	TFR/S 97	TFR 87HP	Isuzu
8-97940254-1	PUMP ASM; OIL	TFS 97	TFS 97	Isuzu
8-97940610-0	LOWER LINK ASM; RH	TFR 98	TFR	Isuzu
8-97940611-0	LOWER LINK ASM.LH	TFR 98	TFR	Isuzu
8-97940612-0	JOINT ASM; LWR (4X2)	TFR	TFR 87HP	Isuzu
8-97940615-0	ROD; TRACK OUTER	TFR	TFR 87HP	Isuzu
8-97940616-0	ROD END; OUTER RH	TFR	TFR 87HP	Isuzu
8-97940617-0	ROD END; OUTER LH	TFR	TFR 87HP	Isuzu
8-97940625-0	JOINT BALL UPR.CONT.	TFR	TFR 87HP	Isuzu
8-97940628-0	CYL; CLUTCH MASTER	TFR 98.5	TFR 88~96	Isuzu
8-97940630-0	CYL; CLUTCH SLAVE 4JA	TFR 98	TFR 87~96	Isuzu
8-97940630-1	CYL; CLUTCH SLAVE 4JA	TFR-2001	TFR 87HP	Isuzu

Part No	Part Names	Models		Brand
8-97940631-0	CYL; CLUTCH SLAVE	TFR 98.5	TFR 97	Isuzu
8-97940640-0	CYL; MASTER	TFR 98.5	TFR 99	Isuzu
8-97940641-0	MASTER VAC ASM; BRK.	TFR 2000	TFR 97	Isuzu
8-97940808-0	SHAFT ASM; PROP	TFR-05	D-MAX 05	Isuzu
8-97940815-3	ABSORBER; SHOCK FRT.	TFS-03	D-MAX	Isuzu
8-97940844-4	ABSORBER; SHOCK RR.	TFS-03	D-MAX	Isuzu
8-97940927-0	CYL.CLUTCH MASTER	TFR-2000	TFR 3.0	Isuzu
8-97941012-0	SHAFT; AXLE RR. (4X2)	TFR		Isuzu
8-97941084-0	KNUCKLE; FRT AXLE RH	TFR	TFR	Isuzu
8-97941085-0	KNUCKLE; FRT AXLE LH	TFR	TFR	Isuzu
8-97941410-0	HINGE; DOOR LWR.F.RH.	TFR 2000	TFR	Isuzu
8-97941411-0	HINGE; DOOR LWR.F.LH.	TFR 2000	TFR	Isuzu
8-97941412-0	HINGE; DOOR UPR.F.LH.	TFR 2000	TFR	Isuzu
8-97941501-3	TANK; SURGE.RAD	TFR-03		Isuzu
8-97941515-0	CYL; CLUTCH SLAVE 4JH	TFR-03	TFR3.0	Isuzu
8-97941521-0	DISC CLUTCH (4JA1)	TFR-03	D-MAX	Isuzu
8-97941522-0	PLATE PRESSURE (4JH1)	TFR-03		Isuzu
8-97941523-0	DISC CLUTCH (4JH1)	TFR-03	D-MAX	Isuzu
8-97941533-0	SHROUND; FAN	TFR-03		Isuzu
8-97941547-0	BRACKET; RAD MTG	TFR-03	D-MAX	Isuzu
8-97941656-0	ANMATURE; STARTER	TFR-4JH1	D-MAX	Isuzu
8-97941663-0	HOLDER ; BRUCH 4JH1	TFR-2001	TFR 2000	Isuzu
8-97941906-0	SUPPORT RUB.E/MT RH	TFR-2001	TFR 3.0	Isuzu
8-97941907-0	SUPPORT RUB.E/MT LH	TFR-2001	TFR 3.0	Isuzu
8-97942193-0	SHAFT:AXLE RR. (4X4)	TFS/UCS	TFS 97	Isuzu
8-97942268-1	CAP; RADIATOR	TFR-03	D-MAX	Isuzu
8-97942296-0	CYL; CLUTCH SLAVE 4JA	TFR-03	D-MAX 2.5	Isuzu
8-97942297-0	RUBBER; MTG, RAD	TFR-03	D-MAX	Isuzu
8-97942313-0	BUSHING ASSIST SPR C	TFR-03	D-MAX	Isuzu
8-97942314-0	BUSHING ASSIST SPR.C	TFR-03	D-MAX	Isuzu
8-97942409-2	AIR CLEANER ASM; 4JH1	TFR-03	D-MAX	Isuzu
8-97942409-3	AIR CLEANER ASM; 4JH1	TFR-03		Isuzu
8-97942410-2	CLEANER ASM; AIR 4JA1	TFR-03	D-MAX	Isuzu
8-97942410-3	CLEANER ASM; AIR 4JA1	TFR-03	D-MAX	Isuzu
8-97942423-3	MEMBER; CROSS, S	UCR/S510	D-MAX	Isuzu
8-97942466-2	PUMP ASM; OIL 4JA/4JH	TFR-03	D-MAX	Isuzu
8-97942518-0	RING SET PISTON 4JA1	TFR-4JA1		Isuzu
8-97942725-0	FAN BELT	TFR-03	D-MAX	Isuzu
8-97942726-0	BELT	TFR-03	D-MAX	Isuzu
8-97942728-0	BELT	TFR-03	D-MAX	Isuzu
8-97942729-0	BELT	TFR-03		Isuzu
8-97942749-0	GASKET; EGR PIPE P10	TFR-03	D-MAX	Isuzu
8-97942751-0	GEAR CRANKSHAFT	TFR-03	D-MAX	Isuzu
8-97942764-0	GEAR CAMSHAFT (4JA)	TFR-03		Isuzu
8-97942803-0	ROD PUSH SLAVE CYL	TFR-03	D-MAX	Isuzu
8-97942843-0	YOKE ASM; SPLINED PRO	TFR-03	D-MAX	Isuzu
8-97942845-1	JOURNAL ASM; PR	TFR-03	D-MAX	Isuzu
8-97942849-0	YOKE; FLANGE PROP 4JH	TFR-03	D-MAX	Isuzu

Part No	Part Names	Models		Brand
8-97942972-0	PUMP ASM; WATER 4JA/B	TFR-03	D-MAX	Isuzu
8-97943022-0	BELT; COOLING 4JH1T	TFR(4JH)	D-MAX	Isuzu
8-97943031-3	ROD ASS'Y CONNE	TFR-03	D-MAX	Isuzu
8-97943037-0	YOKE ASM; SPLINED PP.	TFR-05	D-MAX 06-07	Isuzu
8-97943041-1	JOURNAL ASM.	TFR-05	HLD-EX	Isuzu
8-97943173-0	BELT; COOLING FAN	TFR-05	D-MAX 05	Isuzu
8-97943178-0	SENSOR; VAPOR 4JA/4JH	TFR-03	D-MAX	Isuzu
8-97943184-0	PUMP; FUEL (4JH1)	TFR-03	D-MAX	Isuzu
8-97943195-1	TURBOCHARGER; (4JA1N)	TFR 01	D-MAX 03	Isuzu
8-97943331-0	PLATE PRESSURE (4JA1)	TFR-03		Isuzu
8-97943432-0	CYL; CLUTCH MASTER	TFR-03	D-MAX	Isuzu
8-97943472-0	SENSOR ASM; SEDIMENT	TFR-05	D-MAX	Isuzu
8-97943520-0	STEERING UNIT; W/PWR	TFR-03	D-MAX	Isuzu
8-97943521-1	STEERING UNIT, 4X4	TFS-03	D-MAX	Isuzu
8-97943603-0	SHAFT ASM; PROP	TFR-05	D-MAX 05	Isuzu
8-97943618-0	BUSHING; CHANGE LEVE	TFR-05	D-MAX 05	Isuzu
8-97943624-0	KNUCKLE; FRT.AXLE RH	TFR-03	D-MAX	Isuzu
8-97943625-1	KNUCKLE; FRT.AXLE LH	TFR-03	D-MAX	Isuzu
8-97943626-1	KNUCKLE; FRT AX	TF04CAB4	D-MAX HI-LANDER	Isuzu
8-97943627-0	KNUCKLE; FRT AX	TF04CAB4	D-MAX HI-LANDER	Isuzu
8-97943627-1	KNUCKLE; FRT AX	TF04CAB4	D-MAX HI-LANDER	Isuzu
8-97943628-1	KNUCKLE; FRT AX	TFS-03	D-MAX 4X4	Isuzu
8-97943629-1	KNUCKLE; FRT AX	TFS-03	D-MAX 4X4	Isuzu
8-97943919-0	PLATE; SKID, RAD	TFR-05	D-MAX	Isuzu
8-97943951-0	SEAL; OIL, CR/SH	TFR-05	D-MAX 05	Isuzu
8-97943955-0	GASKET; SLEEVE,	TFR-05	D-MAX 05	Isuzu
8-97944104-0	BELT; A/C CMPR	TFR-05	D-MAX 05	Isuzu
8-97944149-1	CULTCH COOLING FAN	TFR-05	D-MAX 05	Isuzu
8-97944150-0	FAN COOLING 10ໂງ	TFR-05		Isuzu
8-97944430-0	PUMP ASM; OIL	TFR-03		Isuzu
8-97944431-0	SHAFT; STRG, 2ND	TFR-05	D-MAX 4X2	Isuzu
8-97944434-0	SHAFT; STRG.2ND.	TFR-03	D-MAX 4X2	Isuzu
8-97944442-0	SHAFT; AXLE RR. 4X4	TFS-03	D-MAX 4X4	Isuzu
8-97944443-0	SHAFT; AXLE RR.43/11	TFR-03	D-MAX 4X2	Isuzu
8-97944507-2	PRESSURE; PLATE	TFR-07		Isuzu
8-97944509-1	CYLINDER ASM; C	TFR-07	D-MAX 07	Isuzu
8-97944515-0	BOOT KIT STRG HSG	TFR-06	D-MAX 4X4	Isuzu
8-97944564-0	PIN; WHEEL	TFR-07	KBZ 85HP	Isuzu
8-97944565-0	CAP; HUB, FRT.	TFR-07	D-MAX 4X4	Isuzu
8-97944568-0	LINK ASM; STABILIZER	TFS-03	D-MAX	Isuzu
8-97944569-0	LINK ASM; STABILIZER	TFS-03	D-MAX	Isuzu
8-97944570-0	AIR TILTER	TFR-2001	TFR 3.0	Isuzu
8-97944575-0	LINK ASM; STABILIZER	TFR-03		Isuzu
8-97944831-0	PIN, WHEEL, AXLE	TFR-07		Isuzu
8-97945068-1	TENSIONER; CHAI	TFR-06	D-MAX 06	Isuzu
8-97945101-0	JOURNAL ASM; PROP SHA	TFR-07	D-MAX	Isuzu
8-97945102-0	JOURNAL ASM; PROP SHF	TFR-07	D-MAX 05	Isuzu
8-97945177-0	CYL; CLUTCH SLAVE CL	TFR-07	D-MAX 07	Isuzu

Part No	Part Names	Models		Brand
8-97945190-0	ABSORBER ASM; S	UCR/S510	UCR/S5	Isuzu
8-97945201-0	SHOCK FR	UCR/S510	UCR	Isuzu
8-97945259-0	SENSOR; VAPOR 4JA/4JH	TFR-10.5		Isuzu
8-97945260-0	PUMP; FUEL	TFR-10.5		Isuzu
8-97945273-0	WRENCH KIT	TFR-07	D-MAX	Isuzu
8-97945298-0	GASKET; GEAR CA	TFR-05	D-MAX 05	Isuzu
8-97945338-0	GASKET; HD TO C	TFR-05	D-MAX 05	Isuzu
8-97945423-0	BOOT KIT; STRG	TFR-07	D-MAX 07	Isuzu
8-97945438-0	CYLINDER ASM; C	TFR-07	D-MAX 07	Isuzu
8-97945679-0	DISC; CLUTCH	TFR-07	D-MAX	Isuzu
8-97945713-0	PUMP; FUEL	TFR-10.5	D-MAX 07/10	Isuzu
8-97945851-0	LEVER; CHANGE	TFR-03	D-MAX	Isuzu
8-97946171-0	DISC; CLUTCH (4JJ-TCX)	TFR-07	D-MAX 07	Isuzu
8-97946252-0	BEARING; SHAFT ASM.; PROP	TFR-03		Isuzu
8-97946253-0	BEARING ASM; CTR, M/T	TFS-03	D-MAX 4X4	Isuzu
8-97946649-0	SHOCK RR	TFR-08	D-MAX 05	Isuzu
8-97946661-0	SHOCK FR	TFR-08	D-MAX 08	Isuzu
8-97946663-0	ABSORBER ASM; SHOCK, (KYB.)	TFR-08	D-MAX	Isuzu
8-97946665-0	SHOCK RR	TFR-08	D-MAX 06	Isuzu
8-97946668-0	SHOCK RR	TFR-08	D-MAX 4X2	Isuzu
8-97946678-0	SHOCK FR	TFR-07	D-MAX 4X2	Isuzu
8-97946697-0	PUMP ASM; P/STRG (N)	TFR-03		Isuzu
8-97946698-0	PUMP ASM; POWER	TFR-07		Isuzu
8-97946811-0	SRPING ASM; LEAF.RR	TFR-08		Isuzu
8-97946817-0	SPRING; SIDE AIR OUT	TFR-08		Isuzu
8-97947500-0	BELT; COOLING FAN	TFR-05	D-MAX 05	Isuzu
8-98002241-0	GUARD; MUD, RR	TFR-05	D-MAX 4X2	Isuzu
8-98002242-0	GUARD; MUD, RR	TFR-05		Isuzu
8-98002698-0	REPAIR KIT; OIL	TFR-05	D-MAX 05	Isuzu
8-98002758-0	GLASS; RR DOOR	TFR-06	D-MAX CAB 4	Isuzu
8-98003994-0	HOSE; WATER, RAD	TFR-03	D-MAX	Isuzu
8-98003995-0	HOSE; WATER RAD.	TFR-03	D-MAX	Isuzu
8-98003996-0	HOSE; WATER, RAD	TFR-03	D-MAX	Isuzu
8-98004217-0	FINISHER; RR DOOR LH	TFR-CAB4		Isuzu
8-98004218-0	FINISHER; RR.DOOR RH.	TFR-CAB4		Isuzu
8-98004219-0	WEATHERSTRIP; FT.DR.R	TFR-03		Isuzu
8-98004221-0	WEATHERSTRIP; F	TFR-05		Isuzu
8-98004222-0	WEATHERSTRIP; F	TFR-05		Isuzu
8-98004223-0	FISISHER; RR DOOR LH	TFR-05		Isuzu
8-98004224-0	FINISHER; RR DO	TFR-05		Isuzu
8-98004225-0	WEATHERSTRIP; F	TFR-03		Isuzu
8-98004226-0	WEATHERSTRIP; F	TFR-03		Isuzu
8-98004227-0	WEATHERSTRIP; RR DR.L	TFR-CAB4		Isuzu
8-98004228-0	WEATHERSTRIP; R	TFR-CAB4	D-MAX CAB 4	Isuzu
8-98005407-0	RELAY; MAIN	TFR-06	D-MAX	Isuzu
8-98005814-0	SHACKLE; RR SPRING	TFR/S-07	D-MAX 4X4	Isuzu
8-98005815-0	SHACKLE; RR SPR	TFR/S-07	D-MAX 07	Isuzu
8-98005826-0	JOINT ASM; BALL	TFR-07		Isuzu

Part No	Part Names	Models		Brand
8-98005827-0	JOINT ASM; BALL	TFR-07	D-MAX 4X2	Isuzu
8-98005829-0	BRACKET; FRT S/	TFR-07	D-MAX 07	Isuzu
8-98005832-0	ARM; LWR CONT	TFR-07	D-MAX 07	Isuzu
8-98005833-0	ARM; LWR CONT	TFR-07	D-MAX 07	Isuzu
8-98005834-0	ARM; LWR CONT	TFR-07	D-MAX 07	Isuzu
8-98005835-0	ARM; LWR CONT	TFR-07		Isuzu
8-98005836-0	ARM; UPR CONT	TFR-07	D-MAX	Isuzu
8-98005837-0	ARM; UPR CONT	TFR-07		Isuzu
8-98005838-0	ARM; UPR CONT	TFR-07		Isuzu
8-98005839-0	ARM; UPR CONT	TFR-07		Isuzu
8-98005874-0	JOINT ASM; BALL	TFR-07		Isuzu
8-98005875-0	JOINT ASM; BALL	TFR-07	TFS	Isuzu
8-98005919-0	ARM; HEIGHT CON	TFR-07	D-MAX 07	Isuzu
8-98005920-0	ARM; HEIGHT CON	TFR-07	D-MAX 07	Isuzu
8-98005922-0	CLAMP; STAB TO ROD	TFR-07	D-MAX 07	Isuzu
8-98006055-0	HUB CAB	TFR-07	TFR 87HP	Isuzu
8-98006065-0	BOLT; BRK, DISC TO HUB	TFR-07		Isuzu
8-98006084-0	GENERATOR ASM	TFR-07	D-MAX 07	Isuzu
8-98006255-0	BOLT; BRKT DISC BRK	TFR-07	D-MAX 07	Isuzu
8-98006256-0	PIN; GUIDE	TFR-07	D-MAX	Isuzu
8-98006257-0	PIN; GUIDE	TFR-07	D-MAX	Isuzu
8-98006462-0	BULB ASM; BEZEL	TFR-06	D-MAX	Isuzu
8-98006533-1	CALIPER; FRT DI	TFR-07	D-MAX 07	Isuzu
8-98006534-1	CALIPER; FRT DI	TFR-07	D-MAX 07	Isuzu
8-98006537-1	CALIPER; FRT DI	TFR-07	D-MAX 07	Isuzu
8-98006538-1	CALIPER; FRT DI	TFR-07	D-MAX 07	Isuzu
8-98006704-0	HOSE; FLEX, FRT	TFR-07	D-MAX 07	Isuzu
8-98006941-0	CYLINDER ASM;	TFR/S-07		Isuzu
8-98007007-1	CABLE; PARKING	TFR-07	D-MAX 07	Isuzu
8-98007008-1	CABLE; PARKING	TFR-07	D-MAX 07	Isuzu
8-98007010-1	CABLE; PARKING	TFR-07	D-MAX 07 4X4	Isuzu
8-98007011-1	CABLE; PARKING	TFR-07	D-MAX 07	Isuzu
8-98007034-0	STEM ASM; PARKI	TFR/S-07	D-MAX 07	Isuzu
8-98007129-3	LINER; INNER	TFR/S-07	D-MAX 07	Isuzu
8-98007130-3	PANEL; WHEEL HO	TFR/S-07	D-MAX 07	Isuzu
8-98007131-1	PANEL; WHEEL HO	TFR/S-07	D-MAX 07	Isuzu
8-98007131-3	PANEL; WHEEL HO	TFR/S-07	D-MAX 07	Isuzu
8-98007132-3	PANEL; WHEEL HO	TFR/S-07	D-MAX 07	Isuzu
8-98007151-4	BUMPER ASM; FRT	TFR-07	D-MAX 07	Isuzu
8-98007153-2	BUMPER ASM; FRT	TFS-07	D-MAX 07 4X4	Isuzu
8-98007155-2	BUMPER ASM; FRT	UCR/S-07	MU-7 07	Isuzu
8-98007157-1	BEZEL; FOG LAMP	TFR-07	D-MAX 07	Isuzu
8-98007158-0	BRACKET; FRT BU	TFR/S-07	D-MAX 07	Isuzu
8-98007966-0	LEVER; PARKING BRK	TFR-07		Isuzu
8-98007967-0	LEVER; PARKING BRK	TFR-07		Isuzu
8-98007979-0	ADJUSTER; RR BRK RH	TFR-07	D-MAX 07	Isuzu
8-98007980-0	RR BRK ADJ	TFR-07	D-MAX 07	Isuzu
8-98008006-0	SPRING; SHOE RET	TFR-07		Isuzu

Part No	Part Names	Models		Brand
8-98008007-0	SPRING; SHOE RET	TFR-07		Isuzu
8-98008112-0	NOZZLE; WINDSHI	TFR-07	D-MAX 07	Isuzu
8-98008408-0	PIPE EXH	TFR-06		Isuzu
8-98008687-0	SENSOR; MASS AI	TFR-07		Isuzu
8-98008888-2	CLEANER ASM; AI	TFR-08	D-MAX 08	Isuzu
8-98008889-2	CLEANER ASM; AIR	TFR-07	D-MAX 07	Isuzu
8-98009204-0	AL.WHEEL; 6.5X15	TFR-07	D-MAX 07	Isuzu
8-98009341-0	RETAINER; RR AX	TFR-05	D-MAX 05	Isuzu
8-98009804-0	MOTOR GEAR WINDOW	TFR-07	D-MAX 07	Isuzu
8-98009810-2	GEAR; WINDOW	TFR-07	D-MAX 07	Isuzu
8-98009811-2	GEAR; WINDOW	TFR-07	D-MAX 07	Isuzu
8-98011476-0	ADAPTER; HEADLA	TFR-07	D-MAX 07	Isuzu
8-98011503-3	PUMP ASM; OIL	TFR-07	D-MAX 07	Isuzu
8-98011504-1	PIPE; OIL, TURBOCHARG	TFR-07		Isuzu
8-98011892-3	TURBO ASM	TFR-07	D-MAX 07	Isuzu
8-98012187-0	LOCK; DOOR, FRT	TFR-07		Isuzu
8-98012190-0	LOCK; DOOR, FRT	TFR-07		Isuzu
8-98012197-0	LOCK; DOOR, RR D	TFR-07	D-MAX 07	Isuzu
8-98012198-0	LOCK; DOOR, RR D	TFR-07	D-MAX 07	Isuzu
8-98012203-0	DOOR STRIKER; DOOR	TFR-07	D-MAX 07	Isuzu
8-98012479-1	GRILLE; RAD	TFS-07	D-MAX 07	Isuzu
8-98012482-1	GRILLE; RAD	TFR/S-07	D-MAX 07	Isuzu
8-98012483-2	GRILLE RADIATOR	TFR-07	D-MAX 07	Isuzu
8-98012484-0	MLDG: GRILLE	TFR-07	D-MAX 07	Isuzu
8-98012487-0	MLDG: GRILLE	TFR-07	D-MAX 07	Isuzu
8-98012491-0	MLDG: GRILLE CHROM	TFR-07	D-MAX 07	Isuzu
8-98012492-0	MLDG: GRILLE CHROM	TFR-07	D-MAX 07	Isuzu
8-98012493-0	MLDG: GRILLE CHROM	TFR-07	D-MAX 07	Isuzu
8-98012494-0	MLDG: GRILLE CHROM	TFR-07	D-MAX 07	Isuzu
8-98012495-0	MLDG: GRILLE CHROM	TFR-07	D-MAX 07	Isuzu
8-98012496-0	MLDG: GRILLE CHROM	TFR-07	D-MAX 07	Isuzu
8-98012821-3	GRILLE INNER	UCR/S-07	MU-7	Isuzu
8-98012835-0	WASHER; LK.COOLING.FA	TFR-07	FVM-Z	Isuzu
8-98013383-1	PAN ASM; OIL	TFS-07	D-MAX 07 4X4	Isuzu
8-98013392-0	PLUG; GLOW	TFR-07	D-MAX 05	Isuzu
8-98013911-0	VALVE; EGR	TFR-07	D-MAX 07	Isuzu
8-98013911-1	VALVE; EGR	TFR-07	D-MAX 07	Isuzu
8-98014766-0	COIL ASM; SIR	TFR-07	D-MAX 07	Isuzu
8-98017027-1	THERMAL CAP 85c	NLR 08		Isuzu
8-98017270-0	GASKET; PIPE TO	TFR-06	TFR	Isuzu
8-98017627-0	SWITCH; PARKING	TFR-07	D-MAX 07	Isuzu
8-98018035-0	SHOE KIT; BRK, R	TFR-07		Isuzu
8-98018036-0	SHOE KIT; BRK, R	TFR-07		Isuzu
8-98018761-1	REPAIR KIT; CALIPER	TFR-07		Isuzu
8-98018762-1	REPAIR KIT; CAL	TFR-07	D-MAX2007	Isuzu
8-98019686-0	SWITCH; POWER W	UCR/S-06	UCR/S	Isuzu
8-98019687-0	SWITCH; POWER W	UCR/S-06	UCR/S	Isuzu
8-98020880-0	BEARING ASM; CT	NP/NQ-06	NPR 115HP	Isuzu

Part No	Part Names	Models		Brand
8-98023359-0	LAMP ASM; RR CO	TFR-05		Isuzu
8-98023360-0	LAMP ASM; RR CO	TFR-05		Isuzu
8-98023650-0	M/FENDER RR RH	TFR/S-07	D-MAX 07	Isuzu
8-98023653-0	MOLDING; FENDER	TFR/S-07	D-MAX 07	Isuzu
8-98023657-0	COVER; MUD.FENDER RR	TFR-07	D-MAX 07 4X4	Isuzu
8-98023717-0	SENSOR; WATER T	TFR-07		Isuzu
8-98024141-1	MOLDING; WHEEL	TFR/S-07	D-MAX 07 4X2	Isuzu
8-98024144-1	MOLDING; WHEEL	TFR/S-07	D-MAX 07 4X2	Isuzu
8-98024166-1	MOLDING; WHEEL	UCR/S-07		Isuzu
8-98024171-1	MOLDING; WHEEL	UCR/S-07	MU-7 07-08	Isuzu
8-98024386-0	BULB; FOG LAMP	TFR-03	D-MAX	Isuzu
8-98025265-2	EXTENSION; FRT	TFR-07	D-MAX 07	Isuzu
8-98025403-3	FILTER & COOLER	TFR-07	D-MAX 07	Isuzu
8-98025403-4	FILTER & COOLER	TFR-10.5	D-MAX 07	Isuzu
8-98027480-0	FILTER; ACL	TFR-07	D-MAX 07	Isuzu
8-98027490-0	EMBLEM "LS"	TFR-07	D-MAX 07	Isuzu
8-98027832-0	PLIER	TFR-07	D-MAX	Isuzu
8-98027833-0	DRIVER SCREW	TFR-07	D-MAX	Isuzu
8-98027834-0	WERNCH; WHEEL	TFR-07	D-MAX	Isuzu
8-98027837-0	BAND RUBBER JACK	TFR-07		Isuzu
8-98028116-0	PISTON GRADE A 4JJ	TFR-07	D-MAX 07	Isuzu
8-98028117-0	PISTON GRADE B 4JJ	TFR-07	D-MAX 07	Isuzu
8-98028118-0	PISTON GRADE C 4JJ	TFR-07		Isuzu
8-98028199-0	STARTER ASM	TFR-05		Isuzu
8-98030124-0	LAMP ASM; FOG	TFR-03	D-MAX	Isuzu
8-98030125-0	FOG LAMP	TFR-03	D-MAX	Isuzu
8-98030167-0	BUMPER CORNER RR LH	TFR/S-07	D-MAX 07	Isuzu
8-98030167-1	BUMPER; RR	TFR/S-07	D-MAX 07	Isuzu
8-98030170-0	REINFORCEMENT;	TFR/S-07	D-MAX 07	Isuzu
8-98030172-1	BAR; BACK, RR	TFR/S-07	D-MAX 07	Isuzu
8-98030174-1	PAD; CENTER, BUMPER RR	TFR/S-07	D-MAX 07	Isuzu
8-98030181-0	BUMPER; RR	TFR/S-07	D-MAX 07	Isuzu
8-98030385-0	DRUM; BRK, RR (8-97238630-0)	TFR-03	D-MAX 4X4	Isuzu
8-98030415-0	GUARD RR BUMPER RH	TFR/S-07	D-MAX 07	Isuzu
8-98030416-0	GUARD RR BUMPER LH	TFR/S-07	D-MAX 07	Isuzu
8-98030883-0	MOLDING; WINDSH	TFR-03	D-MAX	Isuzu
8-98030884-0	MOLDING; WINDSH	TFR-03	D-MAX	Isuzu
8-98030933-0	MOLDING; ROOF	TFR-03	D-MAX	Isuzu
8-98030934-0	MOLDING; ROOF	TFR-03	D-MAX	Isuzu
8-98030937-0	MOLDING; ROOF RH	TFR-CAB4		Isuzu
8-98030938-0	MOLDING; ROOF LH	TFR-CAB4		Isuzu
8-98031229-0	ARM HOOD LOCK	TFR-07	D-MAX 07	Isuzu
8-98032675-0	FLASHER; UNIT	TFR-03	TFR	Isuzu
8-98032796-0	STICKER;	TFS-07	D-MAX 07	Isuzu
8-98035681-0	SWITCH; REV LAM	TFR-07	D-MAX 07	Isuzu
8-98036593-A	SEAL		TFR	Isuzu
8-98036594-0	SEAL	TFR-07	TFS	Isuzu
8-98036594-A	SEAL		TFS	Isuzu

Part No	Part Names	Models		Brand
8-98036595-0	SEAL; OIL, NKUCK	TFR-07	TFS 90HP	Isuzu
8-98036670-0	CASE; RR AXLE	TFR-03	D-MAX	Isuzu
8-98037543-0	COVER; SEAL, NOZ	TFR-07	D-MAX 07	Isuzu
8-98040102-0	PANEL; ENG HOOD	TFR-03		Isuzu
8-98040810-0	PISTON; FR DISC BRK	TFR-07	D-MAX 4X2	Isuzu
8-98040811-0	PISTON; FR DISC BRK	TFR-07	D-MAX 07	Isuzu
8-98042901-0	DOOR ASM; REAR LH	TFR-CAB4	D-MAX CAB4	Isuzu
8-98044027-0	COVER, RR ASHTRAY	TFR-07		Isuzu
8-98044180-0	ANTENNA	TFR-07	D-MAX 03	Isuzu
8-98046281-0	METER COMPL; CL	TFR-07		Isuzu
8-98046692-0	HOODj FR	TFR-07		Isuzu
8-98046693-0	HOODj FR	TFR-07	D-MAX 07	Isuzu
8-98047110-0	GLASS; CLUSTER METER	TFR-07		Isuzu
8-98047111-0	GLASS; CLUSTER METER	TFR-07	D-MAX 07	Isuzu
8-98047112-0	PANEL; CLUSTER	TFR-07	D-MAX 07	Isuzu
8-98047113-0	PANEL; CLUSTER	TFR-07		Isuzu
8-98047661-0	SWITCH SEDIMENT FILTER	TFR-05	D-MAX 07	Isuzu
8-98047676-0	RADIATOR	TFR-07	D-MAX	Isuzu
8-98047691-0	REPAIR KIT; BRK	TFR-07	D-MAX 07	Isuzu
8-98048333-0	FILTER ASM; FUE	TFR-07	D-MAX 07	Isuzu
8-98048401-0	SENSOR; SPD.FT.WHL.LH	TFR-03		Isuzu
8-98048402-0	SENSOR; SPD, FRT	TFS-03		Isuzu
8-98048403-0	SENSOR; SPD, FT.WHL.LH	TFS-03		Isuzu
8-98049394-0	RESISTOR; BLOWER UNIT	TFR-07	D-MAX 07	Isuzu
8-98049886-0	BUMPER ASM; FRT	TFS-07	D-MAX 07	Isuzu
8-98050279-0	LATCH; END GATE	TFR-05	D-MAX 07	Isuzu
8-98050281-0	LATCH; END GATE	TFR-05	D-MAX 07	Isuzu
8-98050467-0	LINK ASM; TAIL	TFR-07	D-MAX	Isuzu
8-98050605-0	H/OUTSIDE DR.RH	TFR-03	D-MAX	Isuzu
8-98050606-0	H/OUTSIDE DR.LH	TFR-03	D-MAX	Isuzu
8-98050615-0	HANDLE OUTSIDE RR R	TFR-CAB4	D-MAX CAB4	Isuzu
8-98050616-0	HANDLE OUTSIDE RR R	TFR-CAB4		Isuzu
8-98050664-0	HINGE; ENG.HOOD	TFR-03	D-MAX	Isuzu
8-98050665-0	HINGE; ENG.HOOD	TFR-03	D-MAX	Isuzu
8-98051007-0	BRACKET; P/S	TFR-07	D-MAX	Isuzu
8-98051114-0	PAD KIT; CALIP FR.4X2	TFR-08	D-MAX 08 4X2	Isuzu
8-98051115-0	PAD KIT; CALIP FR.4X4	TFS-07	D-MAX 08 4X4	Isuzu
8-98051326-0	RUBBER; CUSHION MTG#1	TFR-03	D-MAX	Isuzu
8-98051327-0	RUBBER; CUSHION	TFR-03	D-MAX	Isuzu
8-98051328-0	RUBBER; CUSHION	TFR-03	D-MAX	Isuzu
8-98051336-0	RUBBER; CUSHION MTG.R	TFR-07	D-MAX 4X4	Isuzu
8-98051338-0	RUBBER; CUSHION	TFR-03	D-MAX	Isuzu
8-98051340-0	RUBBER; CUSHION	TFR-05	D-MAX 05	Isuzu
8-98051342-0	RUBBER; CUSHION	TFR-05	D-MAX 05	Isuzu
8-98051349-0		TFR-07		Isuzu
8-98051828-0		TFR-08	D-MAX 08	Isuzu
8-98052867-2		TFR-08	D-MAX 08	Isuzu
8-98053833-1		TFR-08	D-MAX 08	Isuzu

Part No	Part Names	Models	Brand
8-98053834-1		TFR-08	Isuzu
8-98054657-0		NKR	Isuzu
8-98054664-0		TFR-07 D-MAX 07	Isuzu
8-98054665-0	HUB; FRT, AXLE 4WD	TFR-07	Isuzu
8-98055744-0	(มีแหวนมาด้วย)	TFR-03 D-MAX	Isuzu
8-98055745-0	BOOT KIT STRG HSG	TFR-06 D-MAX 4X2	Isuzu
8-98055746-0	ROD END ASM; OUTER	TFR-03 D-MAX	Isuzu
8-98056550-0	ROD END; WIPER	TFR-07 D-MAX 07	Isuzu
8-98056551-0	STEERING RACK	TFR-07	Isuzu
8-98057416-0	CLIP WHEEL TRIM	TFR-07 D-MAX 07	Isuzu
8-98057417-0	CLIP WHEEL TRIM	TFR-07 D-MAX 07	Isuzu
8-98057546-0	HINGE; DOOR FR LH	TFR-03 D-MAX	Isuzu
8-98057547-0	HINGE; DOOR FR RH	TFR-03 D-MAX	Isuzu
8-98057548-0	HINGE; DOOR FR RH	TFR-03 D-MAX	Isuzu
8-98057549-0	HINGE; DOOR FR LH	TFR-03 D-MAX	Isuzu
8-98057550-0	HINGE; DOOR RR RH	TFR-CAB4 D-MAX CAB 4	Isuzu
8-98057551-0	HINGE; DOOR RR RH	TFR-CAB4 D-MAX CAB4	Isuzu
8-98057609-0	TANK ASM; WASHER	TFR-03 D-MAX	Isuzu
8-98057621-0	MOTOR WIPER	TFR-03 D-MAX	Isuzu
8-98057978-0	AIR INDUCT ENG	TFR-07 D-MAX 07	Isuzu
8-98060773-0	SUPPORT; FRT BU	TFR-07 D-MAX 07	Isuzu
8-98060774-0	SUPPORT; FRT BU	TFR-07	Isuzu
8-98062142-0	BOLT;	TFR-03 D-MAX 03	Isuzu
8-98062277-0	CYL ASSY, CLUTCH MASTER	NPR-06	Isuzu
8-98063153-0	PUMP ASM; OIL, P	TFR-07 D-MAX 05	Isuzu
8-98070866-0	LAMP; LICENSE PLATE	TFR-05 D-MAX 05	Isuzu
8-98070867-0	LICENSE; LAMP	TFR-05 D-MAX 05	Isuzu
8-98071118-0	CONDENSER ASM;	TFR-05 D-MAX 07	Isuzu
8-98071120-0	CNDSR.SAM; A/C W/FAN	UCR/S510 UCS/S5	Isuzu
8-98071126-0	CONDENSER UNIT	TFR-03	Isuzu
8-98072757-0	CABLE; TRUNK LID&FUEL	TFR-07 D-MAX SPACE CAB	Isuzu
8-98074560-0	PANEL; WHEEL HOUSE LH	TFR-03 D-MAX HLD EX	Isuzu
8-98077180-0	FLYWHEEL ASM; (M/T)	TFR-03 D-MAX	Isuzu
8-98077996-0		TFR-08 D-MAX 08	Isuzu
8-98077997-0		TFR-08 D-MAX 08	Isuzu
8-98078000-0		TFR-08 D-MAX 08	Isuzu
8-98078168-0		TFR-08 D-MAX 08	Isuzu
8-98079019-0	0204-0207	TFR-03 D-MAX	Isuzu
8-98079020-0		208 TFR-03 D-MAX SP/CAB	Isuzu
8-98079104-0		TFR-08 D-MAX 08 4X2	Isuzu
8-98079105-0	REPAIR KIT; CAL	TFR-08 D-MAX 08	Isuzu
8-98080001-0	LAMP ASM; HEAD RH.	TFR-07	Isuzu
8-98080002-0	LAMP ASM; HEAD LH.	TFR-07 D-MAX 07	Isuzu
8-98081668-0	SWITCH; MASTER VAC ASM;	TFR/S-07 D-MAX 07 4X4	Isuzu
8-98088385-0	BELT; A/C CMPR	TFR-08	Isuzu
8-98088684-0	INTER COOLER	TFR-08	Isuzu
8-98088685-0	INTER COOLER	TFR-08 D-MAX 05-09	Isuzu
8-98092087-0	SIGNAL SIDE MIRR RH	TFR-08 D-MAX 08	Isuzu

Part No	Part Names	Models		Brand
8-98092088-0	SIGNAL SIDE MIRR LH	TFR-08	D-MAX 08	Isuzu
8-98092090-0	LEN SIDE MIRROR	UCR/S 08	แพลททินั่ม	Isuzu
8-98094179-0	8-98088684-0 สีเงิน 8-98000192-0	TFR-05	D-MAX 05	Isuzu
8-98096676-0	PISTON RING	TFR-08	D-MAX 05	Isuzu
8-98098586-0	RR LAMP	TFR-07		Isuzu
8-98098587-0	RR LAMP	TFR-07		Isuzu
8-98099947-0	HOASE INTER COOLER	UCR/S 09		Isuzu
8-98101779-0	STEERING ASM.P/S	TFR-07	D-MAX 07	Isuzu
8-98101983-0	NUT WHEEL ALU	TFR-03		Isuzu
8-98102514-0	COVER ENGINE	TFR 08	D-MAX 09	Isuzu
8-98102515-0	COVER ENGINE	TFR 08	D-MAX 08	Isuzu
8-98109369-0	GRILLE CHROME	TFR 09	D-MAX 09	Isuzu
8-98109369-1	GRILLE CHROME	TFR-09	D-MAX 09	Isuzu
8-98109370-1	GRILLE INNER	TFR 09	D-MAX 09 4X4	Isuzu
8-98111488-0	GEAR WINDOW	TFR-07	D-MAX	Isuzu
8-98111489-0	GEAR WINDOW	TFR-07		Isuzu
8-98119278-1	TENSIONER CHAIN	TFR-11	D-MAX 05	Isuzu
8-98119279-0	CHAIN, VALVE TIMING	TFR-06	D-MAX 05	Isuzu
8-98119279-1	CHAIN, VALVE TIMING	TFR-06	D-MAX 05	Isuzu
8-98122038-0	CABLE FR BRK	TFR-07		Isuzu
8-98122039-0	CABLE FR BRK	TFR-07		Isuzu
8-98122042-0	CABLE FR BRK	TFR-07		Isuzu
8-98122043-0	CABLE FR BRK	TFR-07		Isuzu
8-98128134-0	OIL PUMP	NLR 08		Isuzu
8-98130012-0	DOOR GLASS RH	TFR 09	D-MAX	Isuzu
8-98130013-0	DOOR GLASS LH	TFR 09	D-MAX	Isuzu
8-98130014-0	DOOR GLASS LH RR	TFR 09	D-MAX 06	Isuzu
8-98130015-0	DOOR GLASS RH RR	TFR 09	D-MAX CAB 4	Isuzu
8-98130022-0	GLASS; TALL GATE	UCR/S 09		Isuzu
8-98134277-0	FR WINDSHIELD	TFR 09	D-MAX	Isuzu
8-98134280-0	FR WINDSHIELD	TFR 09	TF 04 CAB4	Isuzu
8-98144229-0	FOG LAMP L-R	TFR-07	D-MAX 07	Isuzu
8-98145453-0	FUEL PUMP	TFR-08		Isuzu
8-98146837-0	RELAY STARTER	TFR-03	D-MAX	Isuzu
8-98149982-0	FUEL FILTER	TFR-07		Isuzu
8-98150521-0	GEAR WINDOW RR RH	TFR-07		Isuzu
8-98150522-0	GEAR WINDOW RR	TFR-07		Isuzu
8-98150525-0	GEAR WINDOW RR	TFR-07		Isuzu
8-98150526-0	GEAR WINDOW RR	TFR-07		Isuzu
8-98151593-0	MOTOR GEAR WINDOW RR	TFR-07	D-MAX 07	Isuzu
8-98151594-0	GEAR WINDOW RR	TFR-07	D-MAX 07	Isuzu
8-98152215-0	SHOCK FR	TFR-10.5		Isuzu
8-98152216-0	ABSORBER ASM; SHOCK, (KYB.)	TFR-10.5	HILENDER	Isuzu
8-98152221-0	ABSORBER ASM; SHOCK, RR	TFR-10.5	D-MAX 4X2	Isuzu
8-98152286-0	MOTOR GEAR WIN FR RH	TFR-07	D-MAX 07	Isuzu
8-98152287-0	MOTOR GEAR WIN FR LH	TFR-07	D-MAX 07	Isuzu
8-98158611-0	FR BUMPER	TFR-07		Isuzu
8-98158615-0	FR BUMPER	TFS-07	D-MAX 07 4X4	Isuzu

Part No	Part Names	Models		Brand
8-98159148-0	GRILLE CHROME	TFR-10.5		Isuzu
8-98164742-0	RADIATOR MT	TFR-03	D-MAX	Isuzu
8-98178536-0	BOLT MOUNT BED	TFR-03	D-MAX	Isuzu
9-00032209-0	BEARING; HUB IN	TFR	TFR 87HP	Isuzu
9-00090679-A	BEARING FLYWHEEL	KB/NP/TF	KBD69HP	Isuzu
9-09630026-0	STUD; EXH/M 8X99	FVFTFS		Isuzu
9-12563231-1	SEAT; SPR, LWR	BU	FXM 200HP	Isuzu
9-13713064-A	WATER OUTLET PIPE	TFR	TL 75HP	Isuzu
9-82720209-2	SWITCH; OIL PRESS	TFR-07	KBZ 85HP	Isuzu
ITR87-22803-ZOL	RR LAMP CORNER LH			Isuzu
0-91180210-1	NUT; LOCK ARM			Isuzu
1-09400037-0	DRUM NUT RH&LH	FXM/Z	JCM 160HP	Isuzu
1-11261245-0	LINER; CYL (GRD 3-CX)	6BB/6BD1		Isuzu
1-12528007-0	BUSHING; IDLE SHAFT	FXZ 89		Isuzu
1-41552012-0	WASHER; THRUST	FTR/MT1	FTR	Isuzu
1-43150801-0	ROD END; TIE ROD	FXZGXZ/T		Isuzu
1-43150802-0		FXZGXZ/T		Isuzu
1-48312015-0	DRAIN AIR	FRR-11		Isuzu
1-48320012-2	VALVE ASM; SAFETY	FRR-11		Isuzu
1-51169018-0	WASHER LK; SPRI	FVM-11		Isuzu
5-13660300-0	FAN COOLING	TFR/KBZ	KBZ 85HP	Isuzu
5-13671111-0	BELT; P/S PUMP	TFR	TFR 87HP	Isuzu
5-87311082-0	RING SET; PISTON			Isuzu
8-93290853-3	PANEL; SIDE INN RR LH	TFR-CAB4	D-MAX CAB4,03,	Isuzu
8-93290854-3	PANEL; SIDE INN RR RH	TFR-CAB4	D-MAX CAB4,03	Isuzu
8-94124873-0	DIAPHRAGM; BRK M/CYL.	TFR 98.5	TFR	Isuzu
8-94221150-0	RIVET, PLASTIC	TFR-03	KBZ83 85HP	Isuzu
8-94239501-0		UBSTFR07		Isuzu
8-94255635-3	MIRROR; INSIDE RR.	TFR/S 97	S-CAB	Isuzu
8-94334158-0	RUBBER; CUSHION	TFR		Isuzu
8-94334159-0	SUPPORT RUBBER	TFR		Isuzu
8-94365187-0	WASHER; THRUST T=1.6	TFS-03	D-MAX 03 4X4	Isuzu
8-94367307-0	RUBBER CUSHION	TFR/UBS		Isuzu
8-94392817-0	THERMOSTAT 82C	FTRFV 94		Isuzu
8-94396015-2	CAP; ADJ; SCREW	FRR-11		Isuzu
8-94397310-0	THERMOSTAT 82C	FTRFV 94		Isuzu
8-94399554-0	M10X7	FRR-11		Isuzu
8-94399555-0	M10X4	FRR-11	FRR-11	Isuzu
8-94399605-0	PLUG; RUBBER	NPNQFV/Z		Isuzu
8-94447157-0	VALVE; VACUATOR	TFR-03	D-MAX	Isuzu
8-94453935-0	WASHER; THRUST T=1.5	TFS-03	D-MAX 03 4X4	Isuzu
8-94468660-0	FUSE 20A	TFR-2001	TFR2000	Isuzu
8-94468662-0	FUSE 40A. (GREEN)	TFR 97	TFR 97	Isuzu
8-94473423-A	ROOM LAMP (SMAL)	TFR 95		Isuzu
8-97022017-0	CLIP; DOOR PAD	TFR-03		Isuzu
8-97023019-0	HOSE; WATER, RA	TFR	TFR	Isuzu
8-97035399-0	(41/11, 43/10, 41/9)	TFS/UBS	TFS	Isuzu
8-97062022-0	FUSE 10A. (RED)	TFR 97	D-MAX	Isuzu

Part No	Part Names	Models		Brand
8-97062023-0	FUSE 15A. (BLUE)	TFR 97	UCS	Isuzu
8-97062024-0	FUSE 20A. (YELLOW)	TFR 97	D-MAX	Isuzu
8-97066412-0	WASHER; THRUST T=1.8	TFS-03	D-MAX 03 4X4	Isuzu
8-97070691-2	HOSE : WATER, HTR UN			Isuzu
8-97071561-1	SEAL; OIL, CR/SH	NKTFR-07		Isuzu
8-97112557-0	BRUSH; (+, -) STARTER	TFR-03	D-MAX	Isuzu
8-97138981-99	BOOT; KIT OUTSIDE			Isuzu
8-97144584-0	SEAT; SPRING, LWR	TFR-05		Isuzu
8-97171437-0	PLUG; DRAIN RAD.	FRR-11	D-MAX	Isuzu
8-97184729-0	CARTRIDGE ASM; P/S	TFR-03	D-MAX	Isuzu
8-97234753-7		TFR-03	D-MAX	Isuzu
8-97234966-0	RUBBER; BUMPER STR.RH	TFS-03		Isuzu
8-97234967-0	RUBBER; BUMPER STR.LH	TFS-03		Isuzu
8-97236074-1	LOCK; DOOR FR.DOOR LH	TFR-03		Isuzu
8-97236116-1	WEATHERSTRIP; FT	TFR-03	D-MAX	Isuzu
8-97236117-1	WEATHERSTRIP; FT	TFR-03		Isuzu
8-97241126-1	RAIL; RR.GUIDE FT.RH	TFR-03	D-MAX	Isuzu
8-97241127-1	RAIL; RR.GUIDE FT.LH	TFR-03		Isuzu
8-97245850-2	GENERATOR; 4JH1 60A	TFR-03	D-MAX	Isuzu
8-97250344-1	HOSE; BREATHER	TFR-03	D-MAX 03	Isuzu
8-97287518-2	FILTER ASM; FUE	TFR-03	D-MAX	Isuzu
8-97301381-1	RETAINER; HEADLINING	TFR-CAB4	TFR CAB 4	Isuzu
8-97301477-0	COVER; ADJ HOLE	TFR-03	D-MAX	Isuzu
8-97301492-0	WASHER; LK	TFR-03	D-MAX	Isuzu
8-97301507-0	SPRING; ADJ LEVER RH	TFR-03	D-MAX	Isuzu
8-97301508-0	SPRING; ADJ LEVER LH	TFR-03	D-MAX	Isuzu
8-97301725-0	SCREW; BLEEDER DISC	TFR-03	D-MAX 03	Isuzu
8-97308645-0	REINF; INST PANEL LWR	TFR-03	D-MAX	Isuzu
8-97308646-0	STRIKER; GLOVE BOX	TFR-03	D-MAX 03	Isuzu
8-97311440-2	GRILLE; AIR OUTLET	TFR-03	D-MAX SINGLE	Isuzu
8-97311668-0		TFR-05		Isuzu
8-97311669-0	SPRING; VLV	TFR-05	D-MAX 05	Isuzu
8-97312067-0	GASKEY; INL.MANIFOLD	TFR-05	D-MAX 05	Isuzu
8-97313208-0	SWITCH; DOOR	TFR-03	D-MAX	Isuzu
8-97315231-2		TFR-05	D-MAX	Isuzu
8-97318679-0	CALIPER; FT.DISC RH.	TFS-03	D-MAX 4X4	Isuzu
8-97328229-0	BOOT CALIPER	TFR-03	D-MAX	Isuzu
8-97328512-0	ROD ASM; PUSH, T	UBS 99	UBS 99	Isuzu
8-97328642-7		TFR-10.5	D-MAX 05	Isuzu
8-97328647-0	SEAL; VLV; GUIDE	TFR-05	D-MAX 05	Isuzu
8-97328648-0	SEAL; OIL, FINAL	NKNPNQ06		Isuzu
8-97328866-2		NLR 08		Isuzu
8-97331631-2		TFR-05	D-MAX 05	Isuzu
8-97349476-0	CAP; OIL TANK P/S	TFR-03	D-MAX	Isuzu
8-97349993-0	ACTUATOR; DOOR LK, FRT	TFR-03	D-MAX	Isuzu
8-97349995-0	ACTUATOR; DR LK, FR.RH.	TFR-03	D-MAX	Isuzu
8-97351076-0	CABLE ASM; LOCK RH	TFR-03	D-MAX	Isuzu
8-97351084-0	ACTUATOR; DR, RR/R, LOC	TFR-05	D-MAX	Isuzu

Part No	Part Names	Models		Brand
8-97352836-0		C-190		Isuzu
8-97355408-3	TURBOCHARGER AS	TFR-05	D-MAX 05	Isuzu
8-97355673-2	PISTON	TFR-05	D-MAX 05	Isuzu
8-97356028-2	G/K.EXH.MANIF.TO.HD	TFR-05	D-MAX 05	Isuzu
8-97357525-1	DOOR ASM; REAR	UCR/S510	MU-7	Isuzu
8-97359942-0	FASTENER; MOLDIN	TFR-03	D-MAX 4X4	Isuzu
8-97361770-0	THERMOSTAT	TFR/UBS		Isuzu
8-97367309-3	CASE; TIMING GEAR	TFR-05	D-MAX 05	Isuzu
8-97369016-0	ARM; CHECK, FRT	TFR-03	D-MAX	Isuzu
8-97370562-1	HOSE; RUBBER	TFR-05	D-MAX 05	Isuzu
8-97372920-0	CLUTCH; MAGNET,	TFR-05	D-MAX 05	Isuzu
8-97374978-0	GAUGE; OIL LEVE	TFR-05	D-MAX 4X2	Isuzu
8-97375919-0	VALVE 1 WAY FUEL	TFR-05	D-MAX 05	Isuzu
8-97376443-0	CYLINDER SET; C	TFR-03		Isuzu
8-97379281-0	DUCT; AIR INT	TFR-05		Isuzu
8-97379826-0	RETAINER; CR/SH	TFR-05	D-MAX 05	Isuzu
8-97381612-0	PULLEY; GEN	TFR-03		Isuzu
8-97384015-0	RIVET	TFR-05	D-MAX 05	Isuzu
8-97387368-1		TFR-10.5	D-MAX 07 RODEO	Isuzu
8-97387370-1		TFR-10.5	D-MAX 07 SL SX	Isuzu
8-97387373-1		TFR-10.5	D-MAX 07 RODEO	Isuzu
8-97388502-0		TFR-05	D-MAX 05	Isuzu
8-97388503-0		TFR-05	D-MAX 05	Isuzu
8-97388504-2		TFR-05	D-MAX 05	Isuzu
8-97393894-0	FINISHER; FRT.BUMPER	TFR-03	D-MAX	Isuzu
8-97403478-1	SUN VISOR	TFR/S-07		Isuzu
8-97404939-0	PANEL; DOOR RR RH RH	TFR-07	D-MAX 07	Isuzu
8-97405961-0	COVER; INST SIDE PANEL	TFR-07	D-MAX	Isuzu
8-97409186-0	CONSOLE; RR	TFR-07	D-MAX 07	Isuzu
8-97910010-0	TRIM; DOOR, UPR		TFR 97	Isuzu
8-97910021-0	TREAD PLATE; S R	TFR/S 97	TFR 2.5T	Isuzu
8-97910086-2	HORN; HIGH NOTE	TFR/S 97	TFR	Isuzu
8-97910106-0	(ติดลูกปืน)	TFR/S 97		Isuzu
8-97910150-0	HANDLE; W/REGULATOR	TFR/S 97	S-CAB	Isuzu
8-97910202-0	WATER OUT PIPE 4JA1	TFR 97		Isuzu
8-97910291-1	MUD FLAP; FRT.4W	TFS 97	TFR2.8T	Isuzu
8-97910679-1	HOSE; WATER RAD.INL	TFR-98		Isuzu
8-97910694-5	CABLE ASSYRRLH	TFS 97	TFS 98	Isuzu
8-97910701-0	BOX TRIM PAD; DOOR	TFR 97	S-CAB	Isuzu
8-97910822-0	DISC; CLUTCH (UNI)4JA1	TFR	TFR 87HP	Isuzu
8-97910868-0	BELT; AIR D/CAB 58.5	4JA1-SD	TFR2.5T	Isuzu
8-97910926-0	LOCK ASM; DOOR LH	TFR 97	TFR 2.5T	Isuzu
8-97910927-0	LOCK ASM; DOOR RH	TFR 97	TFR 2.5T	Isuzu
8-97910997-0	HUB CAP; BLACK +HD, GM	HONDA/GM	TFR	Isuzu
8-97911033-0	LINK; RR GATE RH	TFR	TFR	Isuzu
8-97911052-0	BAR; TORSION F/LH.	TFS 97	TFS	Isuzu
8-97911054-0	BAR; TORSION RH (M/T)	TFR 97	TFR 87HP	Isuzu
8-97911095-0	TORSION BAR (M/T)	TFR 97	TFR 87HP	Isuzu

Part No	Part Names	Models		Brand
8-97911115-0	SHACKLE RR.SPR	TFR	TFR 87HP	Isuzu
8-97911277-0	HOSE FILLER NECK	TFR/S 97	TFR	Isuzu
8-97912518-1	FLYWHEEL	TFR*		Isuzu
8-97912536-2	PIPE OIL P/COOL+4JA1	TFR 97	TFR 87HP	Isuzu
8-97912546-0	(ກລັ່ງລະ 20 ລຸກ)	TFR	KBZDI	Isuzu
8-97912611-0	INTAKE DUCT ASM	TFR/S 97	TFR 2.5T	Isuzu
8-97912614-0	BRACKET; PUMP	TFR 97	TFR 97	Isuzu
8-97912621-0	CLIP ASM; INJ	TFR/S 97	TFR 97	Isuzu
8-97912623-0	HOSE; FUEL NOZZLE	TFR/S 97	NKR88HP	Isuzu
8-97912652-0	SEAT SPRING	TFR-03		Isuzu
8-97912688-1	R/HOSE T.FEED +4JB1	TFR-03	D-MAX	Isuzu
8-97912748-0	GEAR; CAMSHAFT	TFR/S 97	TFR 97 2.5	Isuzu
8-97912749-0	GEAR; CRANKSHAFT	TFR/S 97	TFR 97 2.5	Isuzu
8-97912752-0	SHAFT :IDLE GEAR	TFR 97	TFR 97	Isuzu
8-97913292-0	PIPE ASM; OIL	TFR/S 97	TFR 2.5T	Isuzu
8-97913469-0	RUBBER CUSHION	TFR-2001		Isuzu
8-97914623-0	BOLT; CYL.HEAD	TFR	TL	Isuzu
8-97914735-0	HOSE; WATER RAD.OUT	UCS 98	UCS 98	Isuzu
8-97915276-1	RUN; GLASS FRT RH	TFR 97	TFR~	Isuzu
8-97915277-1	RUN; GLASS FRT LH	TFR 97	TFR~	Isuzu
8-97915535-0	RUBBER MTG.EXH.PIPE	TFR-2001	TFR 2000	Isuzu
8-97915776-0	PIPE OIL .OOLER	TFR		Isuzu
8-97916330-09			TFR 2.5T	Isuzu
8-97916331-09	RUBBER; ENG.FRT.		TFR 2.5T	Isuzu
8-97916533-0	PIN:SPRING	NKR-06	NKR	Isuzu
8-97916535-0	SHACKLE; W/PIN	NKR-133		Isuzu
8-97916576-0	HANGER; SPARE TIRE	TFR	KBZ	Isuzu
8-97917419-1	HEADLAMP RH.MR. (BLK)	TFR 98	SLX	Isuzu
8-97917991-2	CLAMP; BATTERY	TFR-2000	TFR 2000	Isuzu
8-97918327-0	SHOCK ABS.FRT (TOKICO	TFR 98	TFR	Isuzu
8-97918328-0	SHOCK ABS; RR. (TOKICO	TFR 98	TFR	Isuzu
8-97918411-0	STAY; FRONT END	TFR-2000	TFR 2000	Isuzu
8-97918503-99			SPARK EX EXL	Isuzu
8-97919145-0	HINGE ASM; E/HOD	TFR-2000		Isuzu
8-97919146-0	HINGE ASM; E/HOO	TFR-2000		Isuzu
8-97919966-0	PLATE ASM; PRESS (4JH1	TFR 2001		Isuzu
8-97920080-2	HOSE O/C RETURN	TFR-2001		Isuzu
8-97920200-3	GASKET; EXH.MANIF	TFR-03	D-MAX	Isuzu
8-97920304-0	PULLEY; 3'GROOVE	TFR/S 97	TFR 87HP	Isuzu
8-97921351-0	SEAL DOOR OTR WAIST	TFR-CAB4	TFS CAB-4	Isuzu
8-97921783-0	COVER FENDER; RH	TFR/S*		Isuzu
8-97921784-0	COVER FENDER;	TFR/S*		Isuzu
8-97940045-0	SEAL; OIL, SHAFT	TFR 97	TFR97	Isuzu
8-97940046-0	SEAL; SECTOR SHAFT	TFR 97	TFR97	Isuzu
8-97940124-0	BEARING; WORM SHAFT	TFR 97	TFR 97	Isuzu
8-97940545-0	HOSE RUBBER SUC	TFR 98	TFR87HP	Isuzu
8-97940708-1	HOSE; FLEX, FR.BRK (4X2	TFR	TFR 97	Isuzu
8-97941070-0	BOLT; CYL HD TO	TFR-03		Isuzu

Part No	Part Names	Models		Brand
8-97941413-0	HINGE; DOOR UPR.F.RH.	TFR 2000	TFR	Isuzu
8-97941667-0	SWITCH; MAGNETIC 4JH1	TFR-2001		Isuzu
8-97942312-0	SPRING; ASSIST CLU	TFR-03		Isuzu
8-97942723-0	EXC.POWER STEERING L=1394 B=13.3	TFR-03	D-MAX	Isuzu
8-97942767-0	EXHAUST MANIFOLD 4JH	TFR-2001		Isuzu
8-97942836-0	CAP; OUTER CLU M/CYL	TFR-03		Isuzu
8-97942942-0	PLUG; SENSOR	TFR-03	D-MAX	Isuzu
8-97943163-1	HOSE; OIL COOLER FEED	TFR-03	TFR 2000	Isuzu
8-97943520-1	STEERING UNIT	TFR-03	D-MAX	Isuzu
8-97943969-0	DISC; CLUTCH 4JH1	TFR 2001		Isuzu
8-97944848-1	PLATE; SKID, RAD	TFR/S-07	D-MAX 07 4X4	Isuzu
8-97945041-2		TFR-05	D-MAX 05	Isuzu
8-97945176-0				Isuzu
8-97945522-4		TFR-07	D-MAX 07	Isuzu
8-97945853-0	ROD GEAR	TFR-03	D-MAX	Isuzu
8-98003164-0	DIAPHRAGM; VENT	TFR-05	D-MAX 05	Isuzu
8-98004195-0	HYDRAULIC UNIT ANTI	TFR-06		Isuzu
8-98004220-0	WEATHERSTRIP; FT.DR.L	TFR-03		Isuzu
8-98004233-0	WEATHERSTRIP; R	TFR-CAB4	TFR CAB4	Isuzu
8-98005826-09	JOINT ASM; BALL UPR		D-MAX 4X4	Isuzu
8-98005842-0	BOLT;	TFR-07	D-MAX 03	Isuzu
8-98005935-0	ABSORBER ASM; S	TFR-07	D-MAX 07	Isuzu
8-98006085-0	ALTERNATOR	UCR/S-07		Isuzu
8-98006254-0	BOLT; BLEEDER DISC BRK	TFR-07	D-MAX 07	Isuzu
8-98007996-0	LEVER; AUTO ADJ RH	TFR-07		Isuzu
8-98007997-0	LEVER; AUTO ADJ RH	TFR-07	D-MAX 07	Isuzu
8-98008002-0	SPRING; SHOE RET	TFR-07	D-MAX 07	Isuzu
8-98008005-0	SPRING; SHOE RET	TFR-07	D-MAX 07	Isuzu
8-98008034-0	PIN; SHOE HOLD DOWN	TFR-07	D-MAX 07	Isuzu
8-98008784-0	HYDRAULIC UNIT;	TFS-07		Isuzu
8-98009797-0	SPRING; SHOE RET	TFR-07	D-MAX 07	Isuzu
8-98011521-0	MANIFOLD; INL	TFR-08	D-MAX 08	Isuzu
8-98014320-0		TFR-08		Isuzu
8-98023661-0	CLIP; MUD GUARD	TFR-07	D-MAX 07	Isuzu
8-98023678-0	REJET MUD FLAP	TFR-07		Isuzu
8-98024143-1		TFR/S-07	D-MAX 07 4X2	Isuzu
8-98024146-1		TFR/S-07	D-MAX 07 4X2	Isuzu
8-98026084-0	CAP; OIL FILLER	TFR-07	D-MAX 07	Isuzu
8-98030173-1	BAR; BACK, RR	TFR/S-07	D-MAX 07	Isuzu
8-98036560-0	SEAL; DUST, DRIV	TFR-07	D-MAX 07	Isuzu
8-98036593-0	SEAL;	TFR-07	TFR 87HP	Isuzu
8-98041186-0	RESISTER ASM; F	TFR-03	D-MAX 03	Isuzu
8-98044179-0				Isuzu
8-98045656-0	PANEL; DOOR RR RH	UCR/S-07	UCR/S	Isuzu
8-98049957-0	SUPPORT; FT.DISC BRK	TFR-07	D-MAX 4X2	Isuzu
8-98050333-0	STRIKER T/G RR.B RH	TFR-03	D-MAX	Isuzu
8-98050334-0	STRIKER; T/G RR B LH	TFR-03	D-MAX	Isuzu
8-98050942-0		TFR-08	D-MAX 08	Isuzu

Part No	Part Names	Models		Brand
8-98051329-0	RUBBER; CUSHION	TFR-03	D-MAX	Isuzu
8-98051348-0	RUBBER; CUSHION	UCR/S 07		Isuzu
8-98053513-0	อู่กลางหลังคา	TFR-08	D-MAX 08	Isuzu
8-98053645-0	MIRROR; INSIDE	TFR-07	D-MAX 07	Isuzu
8-98056037-0	W/STRIP; INLET ENGINE	TFR-07	TFR/S 08	Isuzu
8-98057714-0	PIVOT ASM; FRT	TFR-03	D-MAX	Isuzu
8-98096676-1		TFR-10.5	D-MAX 05	Isuzu
8-98122040-0		TFR-08	D-MAX 08	Isuzu
8-98145455-0		TFR 08	D-MAX 08	Isuzu
8-98150029-0		TFR-07	D-MAX 07	Isuzu
8-98150333-0		TFR-05	D-MAX 09	Isuzu
8-98152217-0		UCR-10.5	UCR/S 08	Isuzu
8-98152229-0		UCR-10.5	UCR/S 04	Isuzu
8-98158617-0		TFS-07		Isuzu
8-98159358-0	PUMP; FUEL (4JJ/4JK)	TFR-10.5	D-MAX 05	Isuzu
8-98164751-0		TFR-07	D-MAX 2.5	Isuzu
8-98169680-0		TFR-07	D-MAX 07	Isuzu
8-98173188-0		TFR-11	D-MAX 06	Isuzu
8-98174898-0	PLUG; GLOW	TFR-07	D-MAX 05	Isuzu
8-98196059-0		TFR-07	D-MAX 07	Isuzu
8-98196060-0	811-0 8-98152287-0	TFR-07	D-MAX 07	Isuzu
8-98196061-0	812-3	TFR-07	D-MAX 07	Isuzu
9-08030743-0	KEY, FEATHER	TFR-07	TFR 87HP	Isuzu
9-09111408-A	508-A			Isuzu
9-12528801-2	BUSH	TL,KS,KA	TL 75HP	Isuzu
9-15339051-0	COVER; DUST	MT1/JCM		Isuzu
9-99999913-0	CAP; FUEL TANK	FX,FT	FXM 200HP	Isuzu